


GB Forced draught gas burners

Progressive two-stage or modulating operation



CE

RS BLU

Code	Model	Type
3897430 - 3897432	RS 68/E BLU	846 T1
3897431 - 3897433	RS 68/E BLU	846 T1
3897630 - 3897632	RS 120/E BLU	847 T1
3897631 - 3897633	RS 120/E BLU	847 T1
3788030 - 3788032	RS 160/E BLU	843 T1
3788031 - 3788033	RS 160/E BLU	843 T1
3788050 - 3788052	RS 160/E BLU	843 T1
3788051 - 3788053	RS 160/E BLU	843 T1
3899800 - 3899810	RS 200/E BLU	1106 T1
3899801 - 3899811	RS 200/E BLU	1106 T1
3899830 - 3899840	RS 200/E BLU	1106 T1
3899831 - 3899841	RS 200/E BLU	1106 T1
3899880 - 3899881	RS 200/E BLU	1106 T81
3899882 - 3899883	RS 200/E BLU	1106 T81
3899884 - 3899885	RS 200/E BLU	1106 T81
3899886 - 3899887	RS 200/E BLU	1106 T81

Manufacturer: RIELLO S.p.A.
Address: Via Pilade Riello, 7
37045 Legnago (VR)
Product: Forced draught gas burner
Model: RS 68/E BLU
RS 120/E BLU
RS 160/E BLU
RS 200/E BLU

These products are in compliance with the following Technical Standards:

EN 676
EN 292

According to the European Directives:

GAD	90/396/EEC	Gas Devices Directive
MD	98/37/EEC	Machine Directive
LVD	73/23/EEC - 2006/95/EC	Low Voltage Directive
EMC	89/336/EEC - 2004/108/EC	Electromagnetic Compatibility

such products are marked as follows:



CE-0085BS0267 (for RS 68/E BLU)
CE-0085BS0268 (for RS 120/E BLU)
CE-0085BS0266 (for RS 160/E BLU)
CE-0085XXXXX (for RS 200/E BLU)

Legnago, 08.08.2007

Mr. G. Conticini
Burners Division Department

A handwritten signature in black ink, appearing to read 'G. Conticini', with a horizontal line underneath.

The quality is guaranteed by a quality and management system
certified in accordance with UNI EN ISO 9001.

Section		Pag.
1	Information and general instructions	4
	1.1 Information about the instruction manual	4
	1.2 Guarantee and responsibility	4
2	Safety and prevention	5
	2.1 Introduction	5
	2.2 Personnel training	5
3	Technical description of the burner	6
	3.1 Burner designation	6
	3.2 Models available	6
	3.3 Burner categories- Countries of destination	7
	3.4 Technical data	7
	3.5 Packaging	8
	3.6 Overall dimensions	8
	3.7 Firing rates	9
	3.8 Burner components	10
	3.9 Burner equipment	10
	3.10 Control box for the air/fuel ratio	11
	3.11 Servomotors	12
4	Installation	13
	4.1 Notes on safety for the installation	13
	4.2 Handling	13
	4.3 Preliminary checks	13
	4.4 Working position	13
	4.5 Securing the burner to the boiler	14
	4.6 Pre-calibration of the combustion head (only for the model RS 120/E BLU)	15
	4.7 Combustion head adjustment	16
	4.8 Assembly of the gas train	18
	4.9 Electrical wiring	19
	4.10 Calibration of the thermal relay	20
5	Start-up, calibration and operation of the burner	21
	5.1 Notes on safety for the first start-up	21
	5.2 Operations before start-up	21
	5.3 Burner start-up	22
	5.4 Final calibration of the pressure switches	22
	5.5 Operator panel with LCD display	24
	5.6 Visualisation and programming modes	25
	5.7 Operation sequence of the burner	30
	5.8 Start-up procedure	31
	5.9 CALC function	33
	5.10 Burner adjustment	33
	5.11 Steady state operation	34
	5.12 Ignition failure	34
	5.13 Burner flame goes out during operation	34
	5.14 Stopping of the burner	34
	5.15 Measuring the ionisation current	34
	5.16 Checking the air and gas pressure on the combustion head	34
	5.17 Final checks (with the burner working):	34
	5.18 List of parameters	35
6	Faults - Possible causes - Solutions	39
	6.1 List of error codes	39
7	Maintenance	43
	7.1 Notes on safety for the maintenance	43
	7.2 Maintenance programme	43
	7.3 Opening the burner	44
	7.4 Closing the burner	44
A	Appendix - Electrical panel layout	45
B	Appendix - Accessories (optional)	52
C	Appendix - Gas supply pressure	53
D	Appendix - Firing rate on basis of air density	55

1.1 Information about the instruction manual

Introduction

The instruction manual supplied with the burner:

- is an integral and essential part of the product and must not be separated from it; it must therefore be kept carefully for any necessary consultation and must accompany the burner even if it is transferred to another owner or user, or to another system. If the manual is lost or damaged, another copy must be requested from the Technical Assistance Service **RIELLO** of the area;
- is designed for use by qualified personnel;
- offers important indications and instructions relating to the installation safety, start-up, use and maintenance of the burner.

Symbols used in the manual

In some parts of the manual you will see triangular DANGER signs. Pay great attention to these, as they indicate a situation of potential danger.

GENERAL DANGERS

The **dangers** can be of **3 levels**, as indicated below.



DANGER

Maximum danger level!

This symbol indicates operations which, if not carried out correctly, cause serious injury, death or long-term health risks.



WARNING

This symbol indicates operations which, if not carried out correctly, may cause serious injury, death or long-term health risks.



CAUTION

This symbol indicates operations which, if not carried out correctly, may cause damage to the machine and/or injury to people.

DANGER: LIVE COMPONENTS



DANGER

This symbol indicates operations which, if not carried out correctly, lead to electric shocks with lethal consequences.

Other symbols



ENVIRONMENTAL PROTECTION

This symbol gives indications for the use of the machine with respect to the environment.



This symbol indicates a list.

Abbreviations used

Ch.	Chapter
Fig.	Figure
Page	Page
Sec.	Section
Tab.	Table

Delivery of the system and the instruction manual

When the system is delivered, it is important that:

- The instruction manual is consigned to the user by the system manufacturer, with the recommendation to keep it in the room where the heat generator is to be installed.
 - The instruction manual shows:
 - the serial number of the burner;
 - the address and telephone number of the nearest Assistance Centre.
 - The system supplier must carefully inform the user about:
 - the use of the system;
 - any further tests that may be necessary before the system is started up;
 - maintenance and the need to have the system checked at least once a year by the manufacturer or another specialised technician.
- To ensure a periodic check, **RIELLO** recommends the drawing up of a Maintenance Contract.

1.2 Guarantee and responsibility

RIELLO guarantees its new products from the installation date, in accordance with the regulations in force and/or the sales contract. At the moment of the first start-up, check that the burner is integral and complete.



WARNING

Failure to observe the information given in this manual, operating negligence, incorrect installation and the carrying out of non authorised modifications will result in the annulment by **RIELLO** of the guarantee that it supplies with the burner.

In particular, the rights to the guarantee and the responsibility will no longer be valid, in the event of damage to things or injury to people, if such damage/injury was due to any of the following causes:

- incorrect installation, start-up, use and maintenance of the burner;
- improper, incorrect or unreasonable use of the burner;
- intervention of unqualified personnel;
- carrying out of non authorised modifications on the equipment;

- use of the burner with safety devices that are faulty, incorrectly applied and/or not working;
- installation of untested supplementary components on the burner;
- powering of the burner with unsuitable fuels;
- faults in the fuel power supply system;
- use of the burner even following an error and/or an irregularity;
- repairs and/or overhauls incorrectly carried out;
- modification of the combustion chamber with inserts that prevent the regular development of the structurally established flame;
- insufficient and inappropriate surveillance and care of those burner components most subject to wear and tear;
- use of non-original **RIELLO** components, including spare parts, kits, accessories and optionals;
- force majeure.

RIELLO furthermore declines any and every responsibility for the failure to observe the contents of this manual.

2.1 Introduction

The **RIELLO** burners have been designed and built in compliance with current regulations and directives, applying the known technical rules of safety and envisaging all the potential danger situations.

It is necessary, however, to bear in mind that the imprudent and clumsy use of the equipment may lead to situations of death risk for the user or third parties, as well as the damaging of the burner or other items. Inattention, thoughtlessness and excessive confidence often cause accidents; the same applies to tiredness and sleepiness.

It is a good idea to remember the following:

- The burner must only be used as expressly described. Any other use should be considered improper and therefore dangerous.

In particular:

it can be applied to boilers operating with water, steam, diathermic oil, and to other users expressly named by the manufacturer;

the type and pressure of the fuel, the voltage and frequency of the electrical power supply, the minimum and maximum deliveries for which the burner has been regulated, the pressurisation of the combustion chamber, the dimensions of the combustion chamber and the room temperature must all be within the values indicated in the instruction manual.

- Modification of the burner to alter its performance and destinations is not allowed.
- The burner must be used in exemplary technical safety conditions. Any disturbances that could compromise safety must be quickly eliminated.
- Opening or tampering with the burner components is not allowed, apart from the parts requiring maintenance.
- Only those parts envisaged by the manufacturer can be replaced.

2.2 Personnel training


The user is the person, body or company that has acquired the machine and intends to use it for the specific purpose. He is responsible for the machine and for the training of the people working around it.

The user:

- undertakes to entrust the machine exclusively to suitably trained and qualified personnel;
- must take all the measures necessary to prevent unauthorised people gaining access to the machine;
- undertakes to inform his personnel in a suitable way about the application and observance of the safety instructions. With that aim, he undertakes to ensure that everyone knows the use and safety instructions for his own duties;
- must inform the manufacturer if faults or malfunctioning of the accident prevention systems are noticed, along with any presumed danger situation.

- Personnel must always use the personal protective equipment envisaged by legislation and follow the indications given in this manual.
- Personnel must follow all the danger and caution indications shown on the machine.
- Personnel must not carry out, on their own initiative, operations or interventions that are not within their province.
- Personnel are obliged to inform their superiors of every problem or dangerous situation that may arise.
- The assembly of parts of other makes, or any modifications, can alter the characteristics of the machine and hence compromise operating safety. The manufacturer therefore declines any and every responsibility for any damage that may be caused by the use of non-original parts.

3.1 Burner designation



3.2 Models available

Designation		Voltage	Code
RS 68/E BLU	TC	3 ~ 400 / 230V - 50Hz	3897430 - 3897432
RS 68/E BLU	TL	3 ~ 400 / 230V - 50Hz	3897431 - 3897433
RS 120/E BLU	TC	3 ~ 400 / 230V - 50Hz	3897630 - 3897632
RS 120/E BLU	TL	3 ~ 400 / 230V - 50Hz	3897631 - 3897633
RS 160/E BLU	TC	3 ~ 230V - 50Hz	3788030 - 3788032
RS 160/E BLU	TL	3 ~ 230V - 50Hz	3788031 - 3788033
RS 160/E BLU	TC	3 ~ 400V - 50Hz	3788050 - 3788052
RS 160/E BLU	TL	3 ~ 400V - 50Hz	3788051 - 3788053
RS 200/E BLU	TC	3 ~ 400V - 50Hz	3899800 - 3899810
RS 200/E BLU	TL	3 ~ 400V - 50Hz	3899801 - 3899811
RS 200/E BLU	TC	3 ~ 230V - 50Hz	3899830 - 3899840
RS 200/E BLU	TL	3 ~ 230V - 50Hz	3899831 - 3899841
RS 200/E BLU	TC	3 ~ 220V - 60Hz	3899880 - 3899881
RS 200/E BLU	TL	3 ~ 220V - 60Hz	3899882 - 3899883
RS 200/E BLU	TC	3 ~ 380V - 60Hz	3899884 - 3899885
RS 200/E BLU	TL	3 ~ 380V - 60Hz	3899886 - 3899887

3 Technical description of the burner

3.3 Technical data

Model			RS 68/E BLU	RS 120/E BLU	RS 160/E BLU	RS 200/E BLU	RS 200/E BLU
Type			846 T1	847 T1	843 T1	1106 T1	1106 T81
Output ⁽¹⁾	maximum	kW	350 - 860	600 - 1300	930 - 1860	1375 - 2400	1375 - 2400
		Mcal/h	301 - 740	516 - 1118	800 - 1600	1183 - 2064	1183 - 2064
	minimum	kW	150	300	300	570	570
			Mcal/h	130	258	490	490
Fuel			Natural gas: G20 (methane gas) - G21 - G22 - G23 - G25 - G31 (only RS 200/E BLU)				
Gas pressure at max. output ⁽²⁾ - Gas: G20/G25		mbar	11.7 / 17.5	22.5 / 33.7	17.7 / 26.5	28 / 35.6	28 / 35.6
Gas pressure at max. output ⁽²⁾ - Gas: G31		mbar	-	-	-	19.6	19.6
Operation			Intermittent (min. 1 stop in 24 hours)				
Standard applications			Boilers: water, steam, diathermic oil				
Room temperature		°C	0 - 40				
Combustion air temperature		°C max	60				
Electrical supply			3 ~ 400V / 230 V 1N ~ 230V +/-10%				3 ~ 220V /380V 1N ~ 220V +/- 10 %
Electric frequency			50 Hz				60 Hz
Fan motor (rating)	rpm		2800	2800	2800	2800	3400
	V		230/400	230/400	230/400	230/400	220
	kW		1,5	2,2	4,5	5,5	4,5
Operating current	A		6.1 - 3.5	8.5 - 4.9	15.8 - 9.1	21.3 - 12.3	15.8 - 9.1
Acceleration current	A		78 - 39	48 - 28	126 - 72	144 - 83	126 - 72
Ignition transformer		V1 - V2 I1 - I2	230 V - 1 x 8 kV 1 A - 20 mA				
Absorbed electrical power		kW max	2	2.8	5.3	6.5	5.3
Protection level			IP 44				
Compliance with EC Directives			98/37 - 90/396 - 89/336 - 2004/108 - 73/23 - 2006/95				
Noise level ⁽³⁾		dBA	77	78.5	80.5	83.0	83.0
Type-approval	class 3 (EN 676)	EC	0085BS0267	0085BS0268	0085BS0266	In progress	-

(1) Reference conditions: Room temperature 20°C - Gas temperature 15°C - Barometric pressure 1013 mbar - Altitude 0m above sea level.

(2) Pressure on the pressure switch socket Fig. 27 with zero pressure in the combustion chamber and at maximum burner output.

(3) Sound pressure measured in manufacturer's combustion laboratory, with burner operating on test boiler and at maximum output.

3.4 Burner categories - Countries of destination

Country of destination	Gas category
AT - CH - CZ - DK - EE - ES - FI - GB - GR - HU - IE - IS - IT - LT - LV - NO - PT - SE - SI - SK - TR	I _{2H}
DE	I _{2ELL}
NL	I _{2L}
FR	I _{2Er}
BE	I _{2E(R)B}
LU - PL	I _{2E}

3.5 Packaging

- The packaging of the burner rests on a wooden platform that is particularly suitable for lift trucks. The overall dimensions of the packaging are shown in the table.
- The weight of the burner complete with its packaging is shown in table.

mm	A	B	C	kg
RS 68/E BLU	1400	780	700	77 - 79
RS 120/E BLU	1400	780	700	83 - 85
RS 160/E BLU	1400	780	1000	96-98
RS 200/E BLU	1400	780	1000	101-103




Fig. 1

3.6 Overall dimensions

The dimensions of the burner are shown in Fig. 2. Bear in mind that inspection of the combustion head requires the burner to be opened and the rear part drawn back on the guides. The dimensions of the open burner are indicated by position I.




Fig. 2

mm	A	B	C	D	E	F ⁽¹⁾	G	H	I ⁽¹⁾	L	M	N	O
RS 68/E BLU	511	312	215	555	840	255-390	189	430	1161-1296	214	134	221	2"
RS 120/E BLU	553	338	215	555	840	255-390	189	430	1161-1296	214	134	221	2"
RS 160/E BLU	681	366	315	555	847	373-503	221	430	1442-1587	230	141	186	2"
RS 200/E BLU	732	427	305	555	872	373-503	222	430	1442-1587	230	141	260	2"

(1) Blast tube: short-long

3.7 Firing rates




Fig. 3

D8615

The **maximum output** is chosen within area A (and B for RS 120/E BLU) of the diagram.

NOTE: to use area B (RS 120/E BLU) as well, the pre-calibration of the combustion head is necessary, as explained in Ch. 4.6.

The **minimum output** must not be lower than the minimum limit of the diagram.

Warning

The firing rate was obtained considering a room temperature of 20°C and an atmospheric pressure of 1013 mbar (approx. 0 m above sea level), with the combustion head adjusted as shown in Ch. 4.7.

RS 200/E BLU

The firing rate refers to the operation with fuel G20 - G25. In case G31 is used, the minimum output goes from 570 to 630 kW.




Fig. 4

The firing rates were obtained in special test boilers, according to EN 676 regulations.

Fig. 4 indicates the diameter and length of the test combustion chamber.

Example

Output 756 kW (650 Mcal/h):
diameter 60 cm,
length 2m.

The coupling is ensured when the boiler is EC type-approved; for boilers or ovens with combustion chambers of very different dimensions compared to those shown in the diagram of Fig. 4, preliminary checks are recommended.

3.8 Burner components




Fig. 5

D7923

1 Combustion head	11 Operator panel with LCD display	21 Gas pressure test point and head fixing screw
2 Ignition electrode	12 Control box for checking flame and air/fuel ratio	22 Air pressure socket
3 Screw for combustion head adjustment	13 Clean contact relay	23 Flame sensor probe
4 Maximum gas pressure switch	14 Filter to protect against radio disturbance	24 Air damper
5 Pipe coupling	15 Flame inspection window	25 Fan air inlet
6 Gas servomotor	16 Ignition transformer	26 Screws to secure fan to pipe coupling
7 Plug-socket on ionisation probe cable	17 Cable grommets for electrical wiring (to be carried out by the installer)	27 Gas input pipe
8 Motor contact maker and thermal relay with reset button	18 Air servomotor	28 Gas butterfly valve
9 Operation on/off switch	19 Air pressure switch (differential type)	29 Boiler fixing flange
10 Terminal board for electrical wiring	20 Guides for opening the burner and inspecting the combustion head	30 Flame stability disc
		31 Bracket for application of output regulator RWF40
		32 Extensions for guides 20) - only for TL versions

3.9 Burner equipment

The burner is supplied complete with:

- Gas train flange
- Flange gasket
- 4 screws to fix the flange: M10 x 35
- Thermal insulation screen
- 4 screws to fix the burner flange to the boiler: M 12 x 35
- PVP kit for leak detection (supplied as standard with RS 120/E BLU, RS 160/E BLU and RS 200/E BLU, accessory supplied upon request for RS 68/E BLU - see Appendix B)
- Instruction manual
- Spare parts list

3.10 Control box for the air/fuel ratio




Fig. 6

Introduction

The control box for the air/fuel ratio (hereafter referred to simply as the control box), that equips the burners of the **RS** range, carries out a series of integrated functions in order to optimise burner functioning, both for single operation and together with other units (e.g. double furnace boiler or more than one generator at the same time).

The basic functions carried out by the control box relate to:

1. flame control;
2. the dosage of air and fuel via the positioning (with direct servocontrol) of the relative valves, excluding the possible play in the mechanical cam calibration systems;
3. the modulation of burner output, on the basis of the load requested by the system, maintaining the pressure or temperature of the boiler at the working values set;
4. the safety diagnostic of the air and fuel circuits, via which it is possible to easily identify any causes of malfunctioning.

Further interfaces and computer communication functions (for remote control or integration in central supervision systems) are available according to the system configuration.

Technical Data

Electrical supply	AC 230V - 15% / +10%
Frequency	50/60 Hz +/- 6%
Internal fuse	6.3 A T
Operation below the nominal value of electrical supply	
Minimum operation value on reduction of electrical supply below nominal value	approx. AC 186V
Minimum operation value on increase in electrical supply towards nominal value	approx. AC 195V
Maximum load of the contacts:	
Fan motor relay	
Nominal power supply	AC 230V, 50/60 Hz
Nominal current	2A
Output factor	$\cos\phi > 0.4$
Alarm exit	
Nominal power supply	AC 230V, 50/60 Hz
Nominal current	1A
Output factor	$\cos\phi > 0.4$
Ignition transformer	
Nominal power supply	AC 230V, 50/60 Hz
Nominal current	2A
Output factor	$\cos\phi > 0.2$
Fuel valves	
Nominal power supply	AC 230V, 50/60 Hz
Nominal current	2A
Output factor	$\cos\phi > 0.4$
Operator panel	
Nominal power supply	DC 5V
Protection level	IP 40
Input power	< 50 mW
Length of cables	
Electrical supply line AC 230V	max. 100m (100 pF/m)
Display	max. 3m (100 pF/m)
Output regulator	max. 20m (100 pF/m)
Remote reset button	max. 20m (100 pF/m)



NOTE

The first start-up, like every further operation for the internal settings of the control box, requires access by means of a password and is only to be carried out by personnel of the Technical Assistance Service who have been specifically trained in the internal programming of the tool.

The information for the first start-up is given below.

3.11 Servomotors

Introduction

The servomotors that equip the burners of the **RS** range work directly on the air damper and the gas butterfly valve, without mechanical lever-ages but via the interposition of an elastic coupling.

They are commanded by the control box, which constantly checks their position by means of a return signal from the optic sensor inside the servomotor.



WARNING

For this reason it is absolutely forbidden to remove the cover of the servomotors.

The position (in degrees) of the servomotors can be seen on the display of the Operator Panel. See Ch. 5.18, Parameter 922, index “0” for fuel servomotor, index “1” for air servomotor.

The servomotors are electrically connected to the control box by means of RAST 2.5 type connectors.

When servicing or replacing the servomotors, take care not to invert the connectors. Follow the indications given in the electrical layouts or the silkscreen printing on the control box cover.



D8271

Fig. 7

Technical data

	Fuel servomotor	Air servomotor
Model	SQM33.4..	SQM33.5..
Type of motor	Stepping motor	
Electrical supply	AC/DC 24V	
IP	IP54	
Firing rate	0 - 90°	
Opening time 0 - 90°	min: 5s, max.: 120s depending on the type of control box	
Torque	1.2 Nm	3 Nm
Input power	7.5 W	10 W
Rotation	Clockwise/anticlockwise (can be selected from the control box)	

4.1 Notes on safety for the installation

After carefully cleaning all around the area where the burner will be installed, and arranging the correct lighting of the environment, proceed with the installation operations.



All the installation, maintenance and disassembly operations must be carried out with the electricity supply disconnected.



The installation of the burner must be carried out by qualified personnel, as indicated in this manual and in compliance with the standards and regulations of the laws in force.

4.2 Handling

The packaging of the burner includes a wooden platform (see Ch. 3.5), so it is possible to move the burner (still packaged) with a transpallet truck or fork lift truck.

With regard to the transport in the obligatory passages, refer to the overall dimensions shown in Fig. 1.



The handling operations for the burner can be highly dangerous if not carried out with the greatest attention: keep any unauthorised people at a distance; check the integrity and suitability of the available means of handling.

Check also that the area in which you are working is empty and that there is an adequate escape area (i.e. a free, safe area to which you can quickly move if the burner should fall).

During the handling, keep the load at not more than 20-25 cm from the ground.



After positioning the burner near the installation point, correctly dispose of all residual packaging, separating the various types of material.

Before proceeding with the installation operations, carefully clean all around the area where the burner will be installed.

4.3 Preliminary checks

Checking the consignment



After removing all the packaging, check the integrity of the contents. In the event of doubt, do not use the burner; contact the supplier.



The packaging elements (wooden cage or cardboard box, nails, clips, plastic bags, etc.) must not be abandoned as they are potential sources of danger and pollution; they should be collected and disposed of in the appropriate places.

Checking the characteristics of the burner

Check the identification label of the burner, showing:

- the model (see **A** in Fig. 8) and type of burner (**B**);
 - the year of manufacture, in cryptographic form (**C**);
 - the serial number (**D**);
 - the data for electrical supply and the protection level (**E**);
 - the electrical input power (**F**);
 - the types of gas used and the relative supply pressures (**G**);
 - the data of the burner's minimum and maximum output possibilities (**H**) (see Firing rate)
- Warning.** The output of the burner must be within the boiler's firing rate;
- the category of the device/countries of destination (**I**).


R.B.L.	A	B	C
D	E	F	H
GAS-KAASU <input checked="" type="checkbox"/>	G	H	H
GAZ-AEPIO	G	H	H
I			RIELLO S.p.A. I-37045 Legnago (VR)
			CE 0085

Fig. 8

D7738



A burner label that has been tampered with, removed or is missing, along with anything else that prevents the definite identification of the burner and makes any installation or maintenance work difficult.

4.4 Operation position

The burner is designed to operate only in the positions **1, 2, 3 and 4**.

Installation **1** is preferable, as it is the only one that allows the maintenance operations as described in this manual. Installations **2, 3 and 4** permit operation but make maintenance and inspection of the combustion head more difficult.

Any other position could compromise the correct operation of the appliance. Installation **5** is prohibited for safety reasons.




Fig. 9

4.5 Securing the burner to the boiler

Introduction

The burners RS 68/E BLU - RS 120/E BLU - RS 160/E BLU and RS 200/E BLU are suitable for working on both flame inversion boilers* (in this case the long head model is recommended) and boilers with a combustion chamber with bottom runoff (three flue gas circulations), from which the best results of low NO_x emissions are obtained.


The maximum thickness of the front hatch of the boiler, complete with refractory, must not exceed (see position "a", Fig. 10):

- 200 mm for RS 68/E BLU - RS 120/E BLU;
- 250 mm for RS 160/E BLU and RS 200/E BLU.

(*) For flame inversion boilers, a kit is available to reduce the CO, if necessary (excluded RS 200/E BLU model). See Accessories in Appendix B.

The kit consists of 5 gas tubes, identical to the other 5 already present in the burner head. In standard conditions, the head of the burner is fitted with a second group of tubes, from which the gas emerges in a different direction compared with the others. With the kit, this second group of tubes is substituted so that all the tubes are the same.

After assembling the kit, check its efficiency by measuring the flue gases and CO.



D1079

Fig. 10

Preparing the boiler

Boring the boiler plate

Make holes in the plate shutting off the combustion chamber, as illustrated in Fig. 11. The position of the threaded holes can be marked using the thermal insulation screen supplied with the burner.





Fig. 11

mm	A	B	C
RS 68/E BLU	195	275 - 325	M 12
RS 120/E BLU	195	275 - 325	M 12
RS 160/E BLU	230	325-368	M 16
RS 200/E BLU	230	325-368	M 16



D7950

Fig. 12

Length of the blast tube

The length of the blast tube must be selected according to the indications provided by the manufacturer of the boiler, and in any case it must be greater than the thickness of the boiler door complete with its refractory. The lengths L available are:

Blast tube 10)	RS 68-120/E	BLU RS 160-200/E BLU
• short	255 mm	373 mm
• long	390 mm	503 mm

For boilers with front flue passes 13) or flame inversion chambers, a protection in refractory material 11) must be inserted between the boiler refractory 12) and the blast tube 10). This protection must not compromise the extraction of the blast tube. See Fig. 12.

For boilers with a water-cooled frontal, a refractory lining is not necessary 11)-12) unless expressly requested by the boiler manufacturer.

Securing the burner to the boiler

Before fixing the burner to the boiler, check from the opening of the blast tube that the probe and the electrode are correctly positioned, as in Fig. 13.

If, in the previous check, the position of the probe or electrode was not correct, remove the screw 1)(Fig. 14), extract the inner part 2)(Fig. 14) of the head, and adjust them.

Do not rotate the probe: leave it as in Fig. 13. If it is located too close to the ignition electrode, the control box amplifier may be damaged.




Fig. 13

Separate the combustion head from the rest of the burner, Fig. 12. To do this, proceed as follows:

- loosen the 4 screws 3) and remove the hood 1);
- remove the screws 2) from the two guides 5);
- disconnect the plug 14), unscrew the grommet 15);
- disconnect the socket from the maximum gas pressure switch;
- remove the two screws 4);
- pull back the burner on the guides 5) by about 100 mm;
- disconnect the probe and electrode leads, then unthread the burner completely from the guides.




Fig. 14

Before fixing the burner to the boiler, check (for the model RS 120/E BLU) if its maximum output is included in area A or B of the firing rate. See Fig. 3.

If it is in area A, no intervention is required.

If it is in area B, it is necessary to pre-calibrate the combustion head, as described in Ch. 4.6.

Once this operation has been carried out, fix the flange 9)(Fig. 12) to the boiler plate, interposing the insulating gasket 8)(Fig. 12) supplied.

Use the 4 screws supplied, with a tightening torque of 35 - 40 Nm, after protecting their thread with anti-seize products.

The seal between burner and boiler must be airtight. After the start-up (see Ch. 5.8), check there is no leakage of flue gases into the external environment.

4.6 Pre-calibration of the combustion head (only for the model RS 120/E BLU)



Remove the 4 circular sectors 1) fixed behind the stability disc, removing the 8 screws 2). See Fig. 15.




Fig. 15

4.7 Adjustment of the combustion head

At this point of the installation, the combustion head is fixed to the boiler as shown in Fig. 14. It is therefore especially easy to adjust, and this adjustment depends only on the maximum output of the burner.

Two adjustments of the head are foreseen:

- external air R1;
- central gas/air R2 (excluded RS 200/E BLU);
- central air R2 (only RS 200/E BLU).

In the diagram of Fig. 17, find the notch at which to adjust both air and central gas/air.

External air adjustment

Rotate the screw 4) until the notch you have found corresponds with the front surface 5) of the flange.



Important

To facilitate adjustment, loosen the screw 6), adjust and then lock.

Central gas/air adjustment (RS 68-12-160/E BLU)

Loosen the 3 screws 1) and rotate the ring nut 2) until the notch you have found corresponds with the index 3). Block the 3 screws 1).

Central air adjustment (RS 200/E BLU)

Loosen the 2 screws 1) and rotate the ring nut 2) until the notch you have found corresponds with the screw 1). Block the 2 screws 1). The RS 200/E BLU burner leaves the factory with the ring nut 2) (B) set to notch 0.

Do not change this value.

Example

RS 68/E BLU, burner output = 500 kW.

The diagram of Fig. 17 shows that the adjustments for this potential are:

- air: R1 = notch 6;
- central gas/air: R2 = notch 2.

NOTE

The diagram indicates the optimum adjustment for a type of boiler according to Fig. 4.




Fig. 16

D7675





Fig. 17

D7998

Note

The adjustments indicated can be modified during the initial start-up.

Once the combustion head adjustment is completed:

- reassemble the burner on the guides 3) at about 100 mm from the pipe coupling 4) - burner in the position shown in Fig. 12;
- insert the probe and electrode cables, then slide the burner as far as the pipe coupling - burner in the position shown in Fig. 18;
- connect the plug of the servomotor 14) (Fig. 12) and tighten the grommet 15) (Fig. 12);
- connect the socket of the maximum gas pressure switch;
- refit the screws 2) on the guides 3);
- fix the burner to the pipe coupling with the screws 1).



CAUTION

When fitting the burner on the two guides, it is advisable to gently draw out the high voltage cable and flame detection probe cable until they are slightly taut.




Fig. 18

D7943

4.8 Assembly of the gas train

- The gas train is type-approved according to standard EN 676 and is supplied separately from the burner, with the code indicated in Appendix B.
- The gas train can enter the burner from the right or left side, depending on which is the most convenient, see Fig. 19.
- The gas train must be connected to the gas attachment 1) (Fig. 19) with the flange 2), the gasket 3) and the screws 4) supplied with the burner.
- The gas solenoids must be as close as possible to the burner, to ensure that the gas reaches the combustion head within the safety time of 3s.
- Ensure that the maximum pressure necessary for the burner is included in the calibration field of the pressure adjuster (colour of the spring): gas train MBC-1900-SE.



See the accompanying instructions for the adjustment of the gas train.




Fig. 19




Fig. 20

- 1 - Gas input pipe
- 2 - Manual valve
- 3 - Vibration damping joint
- 4 - Pressure gauge with pushbutton cock
- 5 - Filter
- 6A - "Threaded" multibloc including:
 - filter (can be replaced)
 - safety valve
 - working valve
 - pressure adjuster
- 6B - "Flanged" multibloc including:
 - safety valve
 - working valve
 - pressure adjuster
- 7 - Minimum gas pressure switch
- 8 - Valve leak detection control device.
In accordance with the standard EN 676, leak detection is compulsory for burners with maximum outputs of more than 1200 kW.
- 9 - Gasket
- 10 - Gasket supplied with burner
- 11 - Gas adjustment butterfly valve
- 12 - Maximum gas pressure switch
- 13 - Gas train/burner adaptor
- supplied upon request separately from the gas train for the flanged versions
- P1 - Pressure at combustion head
- P2 - Upstream pressure of valves/adjuster
- P3 - Pressure upstream from the filter
- L - Gas train supplied separately with the code indicated in Appendix B
- L1 - The responsibility of the installer

The losses of load along the gas supply line are indicated in Appendix C.

4.9 Electrical wiring

Notes on safety for the electrical wiring



- The electrical wiring must be carried out with the electrical supply disconnected.
- Electrical wiring must be carried out by qualified personnel and in compliance with the regulations currently in force in the country of destination. Refer to the electrical layouts given in Appendix A.
- **RIELLO** declines all responsibility for modifications or connections different from those shown in the electrical layouts.
- Check that the electrical supply of the burner corresponds to that shown on the identification label and in this manual. See Fig. 8.
- Do not invert the neutral with the phase in the electrical supply line. Any inversion would cause a lockout due to firing failure.
- The burners RS 68-120-160/E have been approved for intermittent operation. This means they should compulsorily be stopped at least once every 24 hours to enable the control box to perform checks of its own start-up efficiency. Normally the boiler's thermostat/pressure switch ensures the stopping of the burner. If this is not the case, it is necessary to apply in series with IN a timer switch that turns off the burner at least once every twenty-four hours. Refer to the electrical layouts given in Appendix A.
- The electrical safety of the device is obtained only when it is correctly connected to an efficient earthing system, made according to current standards. It is necessary to check this fundamental safety requirement. In the event of doubt, have the electrical system checked by qualified personnel. Do not use the gas tubes as an earthing system for electrical devices.
- The electrical system must be suitable for the maximum input power of the device, as indicated on the label and in the manual, checking in particular that the section of the cables is suitable for the input power of the device.
- For the main power supply of the device from the electricity mains:
 - do not use adapters, multiple sockets or extensions;
 - use an omnipolar switch with an opening of at least 3 mm (overvoltage category) between the contacts, as indicated by the current safety standards.
- Do not touch the device with wet or damp body parts and/or in bare feet.
- Do not pull the electric cables.

If the hood is still present, remove it and proceed with the electrical wiring according to the layouts shown in Appendix A.

Use flexible cables according to standard EN 60 335-1.

All the cables to be connected to the burner are fed through the grommets. See Fig. 21.

The use of the cable grommets can take various forms. By way of example we indicate the following mode:

- 1 - Three-phase power supply
- 2 - Single phase power supply
- 3 - Consents/safety
- 4 - Minimum gas pressure switch
- 5 - Gas valves
- 6 - Available

Cable grommets used in the factory:

- A - Fan motor
- B - Maximum gas pressure switch
- C - Gas servomotor
- D - Air servomotor




Fig. 21

4.10 Calibration of the thermal relay

The thermal relay is used to avoid damage to the motor owing to a strong increase in absorption or the lack of a phase.

For the calibration **2)**, refer to the table given in electrical layout no. 6 in Appendix A.

If the minimum value of the scale of the thermal relay is greater than the rating absorption of the motor, protection is still ensured. This arises when the power supply of the motor is 400V.

To reset, in the case of an intervention of the thermal relay, press the button "RESET" **1)** of Fig. 22.

The button "STOP" **3)** opens the NC (95-96) contact and stops the motor.

To test the thermal relay, insert a screwdriver in the window "TEST/TRIP" **4)** and move it in the sense of the arrow (towards right).




Fig. 22



**Automatic resetting can be dangerous.
This action is not provided for the burner
operation.**

5.1 Notes on safety for the first start-up



The first start-up of the burner must be carried out by qualified personnel, as indicated in this manual and in compliance with the standards and regulations of the laws in force.



Check the correct working of the adjustment, command and safety devices.

5.2 Operations before start-up

- Ensure that the gas supply company has carried out the supply line vent operations, eliminating air or inert gases from the piping.
- Slowly open the manual valves situated upstream of the gas train.
- Adjust the minimum gas pressure switch to the start of the scale.
- Adjust the maximum gas pressure switch to the end of the scale.
- Adjust the air pressure switch to the start of the scale.
- Adjust the pressure switch for the valve leak detection control device (PVP kit), if present, according to the instructions supplied with the kit itself.

Minimum gas pressure switch




Fig. 23

Maximum gas pressure switch




Fig. 24

Air pressure switch



Fig. 25

Pressure switch PVP kit




Fig. 26

- Check the gas supply pressure by connecting a pressure gauge to the pressure test point 1)(Fig. 27) of the minimum gas pressure switch: it must be lower than the maximum allowed pressure of the gas train, as shown on the characteristics label.



An excessive gas pressure can damage the components of the gas train and lead to a risk of explosion.

- Bleed the air from the piping of the gas train, connecting a plastic tube to the pressure test point 1)(Fig. 27) of the minimum gas pressure switch. Take the vent tube outside the building so you can notice the smell of gas.
- Connect two lamps or testers to the two gas line solenoids to check the exact moment at which voltage is supplied. This operation is unnecessary if each of the two solenoids is equipped with an indicator light that signals voltage passing through.



Before starting up the burner, it is good practice to adjust the gas train so that ignition takes place in conditions of maximum safety, i.e. with gas delivery at the minimum.




Fig. 27

5.3 Burner start-up

Feed electricity to the burner via the disconnecting switch on the boiler panel.
Close the thermostats/pressure switches and turn the switch of Fig. 28 to position "1".



Make sure that the lamps or testers connected to the solenoids, or indicator lights on the solenoids themselves, show that no voltage is present. If voltage is present, stop the burner **immediately** and check the electrical wiring.

Carry out the "Start-up procedure", as described on page 31.




Fig. 28

5.4 Final calibration of the pressure switches

Air pressure switch

Adjust the air pressure switch after having performed all other burner adjustments with the air pressure switch set to the start of the scale (Fig. 29).

With the burner working at MIN output, insert a combustion analyser in the stack, slowly close the suction inlet of the fan (for example, with a piece of cardboard) until the CO value does not exceed 100 ppm.

Slowly turn the appropriate knob clockwise until the burner goes into lockout.

Check the indication of the arrow pointing upwards on the graduated scale (Fig. 29). Turn the knob clockwise again, until the value shown on the graduated scale corresponds with the arrow pointing downwards, and so recovering the hysteresis of the pressure switch (shown by the white mark on a blue background, between the two arrows).

Now check the correct start-up of the burner.

If the burner locks out again, turn the knob slightly anticlockwise.

During these operations it may be useful to measure the air pressure with a pressure gauge.

The connection of the pressure gauge is shown in Fig. 29.

The standard configuration is that with the air pressure switch connected in absolute mode. Note the presence of a "T" connection, not supplied.

In certain applications in strong depression situations, the connection of the pressure switch does not allow it to change over. In this case it is necessary to connect the pressure switch in differential mode, applying a second tube between the air pressure switch and the fan suction line mouth. In this case also, the pressure gauge must be connected in differential mode, as shown in Fig. 29.




Fig. 29

Maximum gas pressure switch

Adjust the maximum gas pressure switch after having performed all other burner adjustments with the maximum gas pressure switch set to the end of the scale (Fig. 30).

With the burner operating at maximum output, reduce adjustment pressure by slowly turning the relative knob anticlockwise until the burner locks out.

Turn the knob clockwise by 2 mbar and repeat the start-up of the burner.

If the burner locks out again, turn the knob clockwise again by 1 mbar.




Fig. 30

Minimum gas pressure switch

Adjust the minimum gas pressure switch after having performed all other burner adjustments with the pressure switch set to the start of the scale (Fig. 31).

With the burner operating at maximum output, increase adjustment pressure by slowly turning the relative knob clockwise until the burner locks out.

Then turn the knob anticlockwise by 2 mbar and repeat the burner start-up to ensure it is regular.

If the burner locks out again, turn the knob anticlockwise again by 1 mbar.























Fig. 31

Description of the symbols

The unit of measurement of the size visualised is identified by the presence of a dash in the corresponding unit of measurement.

Description of the keys

Key	Function
	- Adjustment of the fuel servomotor (keep  pressed and adjust the value by pressing  or )
	- Adjustment of the air servomotor (keep  pressed and adjust the value by pressing  or )
	- Access to Parameters Mode P (press, at the same time,  and  plus  or )
	- Enter Parameters Mode - Reset in the event of a lockout - Access to a lower level of the menu - In Service Mode and Info Mode, allows: * the selection of the parameter (flashing symbol) (press the key for <1s) * access to a lower level of the menu (press the key for 1 - 3s) * access to a higher level of the menu (press the key for 3 - 8s) * access to another mode (press the key for > 8s)
	- Reduction of value - Access to a lower point of the modulation curve - Scrolling of the parameters list
	- Increase of value - Access to a higher point of the modulation curve - Scrolling of the parameters list
	Exit function (ESC) (press  and  simultaneously) - Non confirmation of the value - Access to a higher level of the menu

5.6 Visualisation and programming modes


The Operator Panel, and especially the display visualisation, has 4 working modes:

- Normal Mode
- Info Mode (**InFo**)
- Service Mode (**Ser**)
- Parameters Mode (**PArA**)


The information for accessing and operating at the various levels is given below.

Normal Mode


Visualises the operation conditions and allows you to modify the operation point of the burner manually. It does not require any use of the keys of the Operator Panel. It allows access to the other visualisation and programming modes. Some examples in the standard conditions are given below.




The burner is in the request for heat waiting mode, or the selector "0-1" of Fig. 28 is at the "0" position.




The display visualises the various phases of the start-up, ignition and switch-off of the burner. In the example alongside, the display indicates that the burner is in phase 30 (see the diagram of Fig. 34) and there are 12s until the next phase.




The burner is working in the requested load position (in the example alongside, **78.4%**).



The display visualises alternately the error code (in the example alongside, **c: 12**) and the relative diagnostic (in the example **d: 0**).




The system goes into safety mode and the message shown in the next figure appears.



The burner goes into lockout.

The display visualises alternately the lockout code (in the example alongside **c: 4**) and the relative diagnostic (in the example **d: 3**).



The red lock-out lamp is on.

D7716

D7717

The display visualises alternately an error code and a diagnostic, which does not take the system into safety mode.

Reset procedure

D7712

D7713

The burner is in lockout when the red indicator light on the Operator Panel is switched on and the display visualises alternately the lockout code (in the example alongside c: 4) and the relative diagnostic (in the example d: 3).

D7746

To reset, press the “i/reset” key for 1s: the display will show “rESEt”. When the key is released, the lockout signal will disappear and the red indicator light will switch off. The control box is reset.

Manual lockout procedure

If necessary, it is possible to manually block the control box and, consequently, the burner, by pressing the key “i/reset” simultaneously with any other key of the Operator Panel.

With the switch 1-0 in Fig. 28 the burner does not stop immediately, but the switch-off phase is activated.

Manual operation procedure

After the adjustment of the burner and the setting of the points on the modulation curve, it is possible to manually check the operation of the burner along the entire curve.

Example

D7765

The burner is working at the requested load percentage: 20%.

D7766

Press the key “F” for 1 second: “LoAd” is displayed and the load percentage flashes.

D7767

Releasing the key “F”, the standard visualisation appears, with the current load percentage flashing: this means that the burner is working in Manual mode (any outside adjustment is excluded and only the safety devices are active).


D7768

Keep the key “F” pressed and, with the keys “+” or “-”, increase or decrease the load percentage.

To emerge from Manual mode, press simultaneously the keys “+” and “-” (esc) for 3 seconds: the burner will work in Automatic mode and the output will depend on the thermostat/adjustment pressure switch (TR).


5 Start-up, calibration and operation of the burner

From Normal mode, using the keys of the Operator Panel, it is possible to activate one of the three visualisation/programming modes:



Info Mode

Visualises the general system information.
The list of the parameters that can be visualised is given in the table below.
To access this level, press the key “**i/reset**” for 1 - 3s.
Release the key immediately when the display shows “**Info**”.




List of the parameters that can be visualised (in the sequence in which they are visualised)


167	Volumetric delivery of fuel in the unit of measurement selected
162	Operation time with flame
163	Operation time
164	No. of resettable ignitions
166	Total no. of ignitions
113	Identification code of the burner
107	Software version
102	Control box test date
103	Identification code of the control box
104	Identification number of the group of parameters set
105	Version of the group of parameters
143	Reserved
End	

Service Mode

Visualises the log of errors and some technical information regarding the system.
The list of the parameters that can be visualised is given in the table below.
To access this level, press the “**i/reset**” key for more than 3s.
Release the key immediately when the display shows “**SEr**”.



List of the parameters that can be visualised (in the sequence in which they are visualised)

954	Flame intensity (%)
121	Manual setting of output Not defined = automatic operation
922	Position of the servomotors (expressed in degrees, symbol ) 0 = fuel 1 = air
161	Number of errors
701	Log of the errors: 701-725.01, Code
.	
.	
.	
725	

Operating procedure in Info and Service Modes

After access to these levels, the display visualises the number of the parameter (flashing) on the left, and the corresponding value on the right.


If the value is not visualised, press the key “**i/reset**” for 1 - 3s.

To return to the Parameters List, press the key “**i/reset**” for more than 3s, or press simultaneously the keys “**+**” and “**-**” (esc).

To move on to the next parameter, press the key “**+**” or “**i/reset**” for less than 1s. At the end of the list, the display visualises “**End**”.

To move back to the previous parameter, press the key “**-**”.

To return to the Normal/Standard visualisation mode, press the “**i/reset**” key for more than 3s, or press simultaneously keys “**+**” and “**-**” (esc). For a moment the display will show “**OPeRate**”.



Parameters Mode


Visualises and allows you to modify/program the complete list of parameters, shown in the table on page 34. The factory-set parameters are not visible.

The parameters level is subdivided into groups:

100: ParA	General parameters Information and identification data of the system.
200: ParA	Checks on the Burner Type of operation, intervention and safety times of the various phases.
400: Set	Air/Fuel modulation curve Setting of air/fuel adjustment points
500: ParA	Positioning of Servomotors Choice of positions of the air/fuel servomotors in the various phases.
600: ParA	Servomotors Setting and addressing of the servomotors.
700: HIsT	Log of the errors Choice of different visualisation modes for the errors log.
900: dAtA	Process information Visualisation of information for the remote management of the burner.

To access this level, refer to "Access procedure with password".

Once the access procedure has been carried out, the display will show "PArA" for a few seconds.



Select the group of parameters with keys "+" and "-", and confirm by pressing the "i/reset" key.

Within the group you have chosen, scroll through the list with the keys "+" and "-". At the end of the list, the display visualises "End".


To return to Normal visualisation mode, simultaneously press the keys "+" and "-" (esc) twice.

To modify a parameter, refer to "Parameter modification procedure".





All the parameters are checked in the factory. Modification/tampering may compromise the good operation of the burner and cause injury to people or damage to things. In any case, modifications must be carried out by qualified personnel.



Access procedure with password



Press the keys "F" and "A" simultaneously for 1s: for a moment the display will show "CodE", and immediately after you will see 7 dashes, the first one flashing.



With the keys "+" and "-" select the first character of the password (letter or number), and confirm by pressing the key "i/reset".




Once you have confirmed, the sign "-" will appear.

Continue in the same way for the other characters.

After inserting the last character of the password, confirm by pressing the key "i/reset": if the password inserted is correct you will see "PArA" for a few seconds, then you can access the various groups of parameters.

With the keys "+" and "-" select the group you require.




If the password inserted is incorrect, the message "Error" will appear for a moment.

It is then necessary to repeat the procedure.



The password must only be communicated to the qualified personnel or the Technical Assistance Service, and must be kept in a safe place.


Parameter modification procedure



After accessing the level and group of parameters, the display visualises the number of the parameter (flashing) on the left, and the corresponding value on the right.


If the value is not visualised, press the key “**i/reset**” for 1 - 3s.

Find below an example of how to modify the parameter relating to the **pre-purging time** (No. 225).




Press the key “**i/reset**”: the value **20** (seconds) will appear.

Note: the unit of measurement of the time is not visualised but is understood in seconds.



Press the key “**+**” and increase the value to **25** seconds (flashing). Press the key “**i/reset**” to confirm and store.




To return to the list of parameters, press simultaneously the keys “**+**” and “**-**” (esc).

Procedure for inserting and adjusting points on the modulation curve


Nine adjustment/calibration points (P1 ÷ P9) can be inserted in the control box for each servomotor, varying their position by degrees and, consequently, the quantity of air and fuel introduced. The **ignition point P0** is independent of the minimum modulation value. This means that, in the event of difficulty, it is possible to switch on the burner at a value other than the modulation minimum (P1).

To insert or adjust a point, proceed as follows:
Access the Parameters Level (group 400) referring to “Access procedure with password”.




Using the keys “**+**” and “**-**” insert/select the curve point you want and wait for it to flash: this means that the servomotors are now positioned on the values shown on the display and which correspond to the point previously set. It is now possible to insert/modify the position by degrees.

Warning: the set value does not require confirmation.



For the fuel servomotor, keep the key “**F**” pressed (the position in degrees flashes) and press the keys “**+**” or “**-**” to increase or decrease the value.



For the air servomotor, keep the key “**A**” pressed (the position in degrees flashes) and press the keys “**+**” or “**-**” to increase or decrease the value.

Select another point, or exit this area by pressing the keys “**+**” and “**-**” simultaneously (esc).

5.7 Operation sequence of the burner




Fig. 34


List of the phases

Ph00	Lockout phase
Ph01	Safety phase
Ph10	t10 = closure in pause
Ph12	Standby
Ph22	t22 = Uphill train of the fan motor (fan motor = ON, safety valve = ON)
Ph24	The burner moves to the pre-purging position
Ph30	t1 = pre-purging time
Ph36	The burner moves to the ignition position
Ph38	t3 = pre-ignition time
Ph40	TSA1= safety time 1 (ignition transformer ON)
Ph42	TSA1 = safety time 1 (ignition transformer OFF), t42 = pre-ignition time OFF


Ph44	t44 = interval time 1
Ph60	Operation
Ph62	t62 = max. time to reach the low flame (the burner moves to the switch-off position)
Ph70	t13 = post-combustion time
Ph72	The burner moves to the post-purging position
Ph74	t8 = post-purging time
Ph80	t80 = emptying time (valve leak detection)
Ph81	t81 = atmospheric test time (valve leak detection)
Ph82	t82 = filling time (valve leak detection)
Ph83	t83 = pressure test time (valve leak detection)
Ph90	Standby time due to lack of gas

Ph = Phase


5.8 Start-up procedure



Check that the display of the Operator Panel shows the request for heat and “OFF Up_r”: this means it is necessary to set the modulation curve of the burner.



Access the Parameters Level referring to “Access procedure with password”. The display visualises the parameters group **400**; confirm with the key “i/reset”.



The display visualises “run”.

Confirm with the key “i/reset”: the burner **starts up**.

The display visualises in sequence all the various phases and relative times. The phases are those defined on page 29.

Phase 22:

Start of the fan motor.

As the burner is not fitted with a device to check the sequence of the phases, the motor rotation may be incorrect. As soon as the burner starts up, go in front of the cooling fan of the fan motor and check it is rotating anticlockwise. See Fig. 28.

If this is not the case:

- place the switch of Fig. 28 in position “0” and wait for the control box to carry out the switch-off phase;
- **disconnect the electrical supply from the burner;**
- invert the phases on the three-phase power supply.



This operation must be carried out with the electrical supply disconnected.

Phase 24:


The burner goes to the pre-purging position, the air servomotor opens the damper at 90°.

Phases 80, 81, 82, 83:

These phases relate to the valve seal test (for the burner RS68/E this function is not inserted in the factory, as it is optional).

Phase 30:

The count of the pre-purging time pre-set in the factory begins.




Phase 36:

The burner goes to the ignition position, point “P0”, defined in the table on page 31: the display visualises the indication “P0” flashing. If the value proposed is suitable, confirm. Otherwise, modify the ignition point (see “Procedure for inserting and adjusting points on the modulation curve”).



Warning: the values shown in the figure alongside are purely for indication purposes.

Confirm with the key “+”.



Phase 38:

The ignition phase begins and the spark goes off.

Phase 40:

The gas valves open (the count of the safety time begins).

Check the presence of the flame from the special inspection window, and the correctness of the combustion parameters; if necessary, vary the degrees of opening/closing of the air and fuel servomotors.


If the control box goes into lockout, press the keys “+” and “-” (esc) simultaneously: the display visualises alternately the lockout code for flame absence **c: 4**) and the relative diagnostic (**d: 3**).

Resolve the problem, referring to Ch. 5.12.


Reset (see “Reset procedure”): the display visualises “OFF Up_r”.

Repeat the start-up procedure.

Warning: the values inserted previously remain stored.



After ignition (point “P0”), proceed with the calibration of the modulation curve, starting from the minimum point “P1”.
Press the key “+”: the display visualises the indication “P1” flashing and proposes the same settings as for point “P0”. It is possible to modify this value and obtain a modulation minimum different from the ignition point.




After adjusting point “P1”, press the key “+”: the display shows “CALC” for a few seconds. The control box will automatically calculate the points from “P2” to “P8”, distributing them in a straight line, assuming for point “P9” the factory setting (see the table below). These are theoretical and must be checked.
Press the key “+” to check if the settings of point “P2” are suitable. If not, modify the point. Proceed in sequence until point “P9”.



Important: before moving on from one point to the next, wait for the servomotors to reach the position visualised on the display.

During the adjustment of each point, work on the air and gas servomotors, without modifying the position of the gas valve stabiliser.
Halfway through the procedure (i.e. around point P4 or P5), you are advised to measure gas delivery and check that the output is about 50% of the maximum output. If this is not the case, work also on the gas valve stabiliser: in this case however, it is necessary to revise the calibrations of all the points previously set.
Once you have arrived at point “P9”, if the maximum output is not as you wish, work on the gas valve stabiliser: in this case however, it is necessary to revise the calibrations of all the points previously set.
At this point, confirm by pressing simultaneously the keys “+” and “-” (esc): the parameter “546” will appear.
If you want to make the burner work on the entire modulation curve, press simultaneously the keys “+” and “-” (esc): in this way, the parameter “546” will automatically be assigned the value of 100% and the parameter “545” will have a value of 20%.
If you want to make the burner work on a part of the modulation curve, modify the parameters “546” and “545” according to “Parameter modification procedure”.
Press simultaneously the keys “+” and “-” (esc) twice: the display will visualise the current load position.



Factory settings

Point of the curve		Burner			
		RS 68/E BLU	RS 120/E BLU	RS 160/E BLU	RS 200/E BLU
P0	air	20°	20°	20°	20°
	gas	24°	24°	24°	24°
P9	air	90°	90°	90°	90°
	gas	90°	90°	90°	90°

5.9 CALC function




Fig. 35

The diagram of Fig. 35 shows how the fuel modulation curve is modified if the values of point "P5" are changed. By keeping the key "+" pressed for more than 3s, the points from "P6" to "P8" are recalculated. By keeping the key "-" pressed for more than 3s, the points from "P4" to "P2" are recalculated.




Fig. 36

The diagram of Fig. 36 shows the fuel modulation curve when, after the modification of point "P5", the recalculations of all the other points is not carried out.

5.10 Burner adjustment

Output upon ignition

According to the regulation EN 676.

Burners with MAX output up to 120 kW

Ignition can be performed at the maximum operation output level. Example:

- max. operation output: 120 kW
- max. output upon ignition: 120 kW

Burners with MAX output above 120 kW

Ignition must be performed at a lower output than the max. operation output.

If ignition output does not exceed 120 kW, no calculations are required. If ignition output exceeds 120 kW, the regulations prescribe that the value be defined according to the control box safety time "ts":

for "ts" = 3s, ignition output must be equal to, or lower than, 1/3 of max. operation output.

Example

MAX operation output of 450 kW.

The ignition output must be equal to, or less than, 150 kW with ts = 3s

In order to measure the ignition output:

- disconnect the plug-socket 7)(Fig. 5) on the ionisation probe cable (the burner will fire and then go into lockout after the safety time has elapsed);
- perform 10 ignitions with consecutive lockouts;
- on the meter, read the quantity of gas burned: this quantity must be equal to, or lower than, the quantity given by the formula, for ts = 3s:

$$Vg = \frac{Qa \text{ (max. burner delivery)} \times n \times ts}{3600}$$

Vg: volume supplied in ignitions carried out (Sm³)

Qa: ignition delivery (Sm³/h)

n: number of ignitions (10)

ts: safety time (sec)

Example for gas G 20 (9.45 kWh/Sm³):

ignition output 150 kW

corresponding to 15.87 Sm³/h.

After 10 ignitions with lockout, the delivery indicated on the meter must be equal to, or less than:

$$Vg = \frac{15.87 \times 10 \times 3}{3600} = 0.132 \text{ Sm}^3$$

Maximum output

The MAX output must be set within the firing rate of Fig. 3.

Gas adjustment

Measure the gas delivery on the meter.

As a general rule, this value can be found on the table on page 51: just read the gas pressure on the pressure gauge (Fig. 38) and follow the indications given on page 51.

- If it is necessary to reduce it, lower the output gas pressure via the pressure adjuster located beneath the gas valve.
- If it needs to be increased, increase the output gas pressure via the adjuster.

Note

If the gas pressure allows it, by closing the ring nut 2)(Fig. 16) you obtain reductions in the formation of NOx.

If, on the other hand, the gas pressure required by the burner (see Appendix C) is insufficient, open the ring nut 2) further compared with the value indicated in the diagram of Fig. 17.

Check that the combustion is satisfactory and without pulsations.

Air adjustment

If necessary vary the degrees of the air servomotor.

Minimum output

The MIN output must be set within the firing rate of Fig. 3.

5.11 Steady state operation

Burner without modulating operation kit

Once the start-up cycle is completed, the servomotor command moves on to the thermostat/pressure switch TR that controls the pressure or the temperature in the boiler.

- If the temperature or the pressure is low (so the thermostat/pressure switch TR is closed), the burner progressively increases the output as far as the MAX value (point "P9").
- If the temperature or the pressure increases as far as the opening of the thermostat/pressure switch TR, the burner progressively reduces the output as far as the MIN value (point "P1"). And so on.
- The burner switches off when the request for heat is lower than the heat supplied by the burner at MIN output. The thermostat/pressure switch TL opens and the control box carries out the switching off phase (see Ch. 5.7). The damper closes completely to reduce thermal dispersions to a minimum.

Burner with modulating operation kit

See the manual supplied with the regulator.

5.12 Ignition failure

If the burner does not switch on, there is a lockout within 3s of the electrical supply reaching the gas valve.

It may be that the gas does not arrive at the combustion head within the safety time of 3s.

In this case, increase gas delivery upon ignition.

The arrival of the gas at the pipe coupling is shown on the pressure gauge of Fig. 38.

5.13 Burner flame goes out during operation

If the flame accidentally goes out during operation, the control box carries out a recycle (i.e. it repeats the start-up phase once, and makes a further ignition attempt).

If the flame is still absent, the control box goes into lockout.

5.14 Stopping of the burner

The burner can be stopped by:

- intervening on the disconnecting switch of the electrical supply line, located on the boiler panel;
- removing the hood and working on the switch 0-1 of Fig. 28;
- removing the transparent protection that covers the Operator Panel, after loosening the relative screw, and using the Panel itself according to "Manual lockout procedure".

5.15 Measuring the ionisation current

The burner is fitted with an ionisation system to check that a flame is present.

The minimum current for control box operation is 4 μ A. The Operator Panel visualises "30%" (see Parameters List, parameter no. 954).

The burner provides a much higher current, so controls are not normally required. However, if it is necessary to measure the ionisation current, disconnect the plug-socket Ap.37 on the ionisation probe cable and insert a direct current microammeter with a base scale of 100 μ A - see Fig. 37.

Carefully check the polarities!




Fig. 37

5.16 Checking the air and gas pressure on the combustion head




Fig. 38

5.17 Final checks (with the burner working):

- Open the thermostat/pressure switch TL:
 - Open the thermostat/pressure switch TS:
- the burner must stop.
- Rotate the maximum gas pressure switch knob to the minimum end-of-scale position.
 - Rotate the air pressure switch knob to the maximum end-of-scale position.
- the burner must stop in lockout.
- Switch off the burner and disconnect the voltage.
 - Disconnect the minimum gas pressure switch connector.
- the burner must not start
- Disconnect the ionisation probe wire.
- the burner must stop in lockout due to firing failure
- Make sure that the mechanical locking systems on the different adjustment devices are fully tightened.

5.18 List of parameters

Parameter		Number of elements	Unit of meas- urement	Modification	Values interval		Degree of precision	Predefined set- ting	Access mode
No. par.	Description				Min.	Max.			
100	General parameters								
102	Control box identification date	1	-	Reading only	0	255	1		Info Mode
103	Control box identification number	1	-	Reading only	0	65535	1		Info Mode
104	Identification number of the group of parameters set	1	-	Reading only	0	255	1		Info Mode
105	Version of the group of parameters set	1	-	Reading only	0	0xFFFF	1		Info Mode
107	Software version	1	-	Reading only	0	0xFFFF	1		Info Mode
113	Burner identification	1	-	Modification	0	99999999	1	Not defined	Info Mode
121	Manual setting of output Not defined = automatic operation	1	-	Modification / zero setting	0%	100%	0.1%	Not defined	Service Mode
125	Frequency of main power supply 0 = 50 Hz 1 = 60 Hz	1	-	Modification	0	1	1	0	Parameters Mode
126	Brightness of display	1	-	Modification	0%	100%	1%	75%	Parameters Mode
128	Fuel meter: Led pulse valence (led pulses / volumetric flow units)	1	-	Modification	0	400	0.01	0	Parameters Mode
130	Eliminate visualisation error chronology To eliminate the visualisation, set the parameter to 1, then to 2 Answer 0: Process successful Answer -1: Time-out of 1_2 - Sequence	1	-	Modification	-5	2	1	0	Parameters Mode
141	Remote management of control box 0 = off 1 = Modbus 2 = reserved		-	Modification	0	2	1	0	Parameters Mode
142	Standby time before a new attempt in event of fault in communication		s	Modification	0s	7200s	1s	600s	Parameters Mode
143	Reserved		-	Modification	1	8	1	1	Info Mode
144	Reserved		-	Modification	10s	60s	1s	30s	Parameters Mode
145	Peripheral address for Modbus		-	Modification	1	247	1	1	Parameters Mode
146	Baud Rate for Modbus 0 = 9600 1 = 19200		-	Modification	0	1	1	0	Parameters Mode
147	Parity for Modbus 0 = none 1 = odd 2 = even	1	-	Modification	0	2	1	0	Parameters Mode

Parameter		Number of elements	Unit of measurement	Modification	Values interval		Degree of precision	Predefined setting	Access mode
No. par.	Description				Min.	Max.			
148	Selection of the burner operation during the interruption of the switch-over with the system of remote management. 0 = burner switched off With modulating operation the settings of the values are the following: 0...19.9 = burner switched off 20...100 = 20...100% burner modulation field (20% = low flame) These settings adapt to parameters 545 (modulation minimum) and 546 (modulation maximum) With stage operation : 0 = burner switched off, 1st, 2nd, 3rd stage according to the values assigned to P1, P2, P3 No setting = no function in the event of communication interruption	1		Modification / zero setting	0%	100%	0.1%	Not defined	Parameters Mode
161	Total number of errors	1	-	Reading only	0	65535	1	0	Service Mode
162	Hours of operation (that can be reset)	1	h	Reset	0h	999999h	1h	0h	Info Mode
163	Total hours of power supply to control box	1	h	Reading only	0h	999999h	1h	0h	Info Mode
164	Total number of start-ups (that can be reset)	1	-	Reset	0	999999	1	0	Info Mode
166	Total number of start-ups	1	-	Reading only	0	999999	1	0	Info Mode
167	Volumetric delivery of fuel in the selected unit of measurement (that can be reset)	1	-	Reset	0	99999999	1	0	Info Mode
200	Checks on the burner								
201	Burner operation mode (fuel supply line, modulating/stage, servomotors, etc.) -- = not defined (eliminate curves) 1 = Gmod 2 = Gp1 mod 3 = Gp2 mod 4 = Lo mod 5 = Lo 2 stages 6 = Lo 3 stages 7 = Gmod pneu 8 = Gp1 mod pneu 9 = Gp2 mod pneu	1	-	Modification / zero setting	1	9	1	Not defined	Parameters Mode
208	Stopping of the program 0 = deactivated 1 = Pre-purging (Ph24) 2 = Ignition (Ph36) 3 = Interval 1 (Ph44) 4 = Interval 2 (Ph52)	1	-	Modification	0	4	1	0	Parameters Mode
210	Alarm/lockout at start	1	-	Modification	0	1	1	0	Parameters Mode
211	Uphill train fan motor	1	s	Modification	2s	60s	0.2s	2s	Parameters Mode
212	Maximum time to reach low flame	1	s	Modification	0.2s	10 min	0.2s	45s	Parameters Mode
215	Maximum repeats of safety circuit	1	-	Modification	1	16	1	16	Parameters Mode

Parameter		Number of elements	Unit of measurement	Modification	Values interval		Degree of precision	Predefined setting	Access mode
No. par.	Description				Min.	Max.			
221	Gas: selection of flame sensor 0 = QRB... / QRC 1 = ION / QRA	1	-	Modification	0	1	1	1	Parameters Mode
222	Gas: Selection of the pre-purging function 0 = deactivated 1 = activated	1	-	Modification	0	1	1	1	Parameters Mode
223	Maximum repeats of minimum gas pressure switch intervention	1	-	Modification	1	16	1	16	Parameters Mode
225	Gas: Pre-purging time	1	s	Modification	20s	60 min	0.2s	20s	Parameters Mode
226	Gas: Pre-ignition time	1	s	Modification	0.2s	60 min	0.2s	2s	Parameters Mode
230	Gas: Interval 1	1	s	Modification	0.2s	60s	0.2s	2s	Parameters Mode
232	Gas: Interval 2	1	s	Modification	0.2s	60s	0.2s	2s	Parameters Mode
233	Gas: Post-combustion time	1	s	Modification	0.2s	60s	0.2s	8s	Parameters Mode
234	Gas: Post-purging time	1	s	Modification	0.2s	108 min	0.2s	0.2s	Parameters Mode
242	Gas: Emptying time (valve leak detection)	1	s	Modification	0.2s	3s	0.2s	3s	Parameters Mode
243	Gas: Atmospheric test time (valve leak detection)	1	s	Modification	0.2s	60s	0.2s	10s	Parameters Mode
244	Gas: Filling time (valve leak detection)	1	s	Modification	0.2s	3s	0.2s	3s	Parameters Mode
245	Gas: Pressure test time (valve leak detection)	1	s	Modification	0.2s	60s	0.2s	10s	Parameters Mode
261	Oil: Selection of flame sensor 0 = QRB... / QRC... 1 = ION / QRA	1	-	Modification	0	1	1	0	Parameters Mode
265	Oil: Pre-purging time	1	s	Modification	15s	60 min	0.2s	15s	Parameters Mode
266	Oil: Pre-ignition time	1	s	Modification	0.2s	60 min	0.2s	2s	Parameters Mode
270	Oil: Interval 1	1	s	Modification	0.2s	60 min	0.2s	2s	Parameters Mode
272	Oil: Interval 2	1	s	Modification	0.2s	60 min	0.2s	2s	Parameters Mode
273	Oil: Post-combustion time	1	s	Modification	0.2s	60s	0.2s	8s	Parameters Mode
274	Oil: Post-purging time	1	s	Modification	0.2s	108 min	0.2s	0.2s	Parameters Mode
281	Oil: Selection transformer ignition phase TA 0 = brief pre-ignition (Ph38) 1 = long pre-ignition (with fan) (Ph22)	1	-	Modification	0	1	1	0	Parameters Mode
400	Air / fuel modulation curve								
401	Checking fuel servomotor	13	(°)	Modification	0°	90°	0.1°	0°; 0°; 15°; not defined	Parameters Mode
402	Checking air servomotor	13	(°)	Modification	0°	90°	0.1°	0°; 90°; 45°; not defined	Parameters Mode
500	Positioning of servomotors								
501	Position of the fuel servomotor in absence of flame Index 0 = standby position Index 1 = pre-purging position Index 2 = post-purging position	3	(°)	Modification	0°	90°	0.1°	0°; 0°; 15°	Parameters Mode

Parameter		Number of elements	Unit of measurement	Modification	Values interval		Degree of precision	Predefined setting	Access mode
No. par.	Description				Min.	Max.			
502	Position of the air servomotor in absence of flame Index 0 = standby position Index 1 = pre-purging position Index 2 = post-purging position	3	(°)	Modification	0°	90°	0.1°	0°; 90°; 45°	Parameters Mode
545	Minimum modulation limit	1	-	Modification / zero setting	20%	100%	0.1%	Not defined	Parameters Mode
546	Maximum modulation limit	1	-	Modification / zero setting	20%	100%	0.1%	Not defined	Parameters Mode
600	Servomotors								
645	Analogical exit configuration 0 = CC 0...10 V 1 = CC 2...10 V 2 = CC 0 / 2...10 V	1	-	Modification	0	2	1	0	Parameters Mode
700	Log of the errors								
701	Error chronology: 701-725.01.Code	25	-	Reading only	0	255	1	0	Service Mode
•	Error chronology: 701-725.02.Diagnostic code	25	-	Reading only	0	255	1	0	Service Mode
•	Error chronology: 701-725.03.Error class	25	-	Reading only	0	6	1	0	Service Mode
•	Error chronology: 701-725.04.Phase	25	-	Reading only	0	255	1	0	Service Mode
•	Error chronology: 701-725.05.Start-up meter	25	-	Reading only	0	99999999	1	0	Service Mode
725	Error chronology: 701-725.06.Load	25	-	Reading only	0%	100%	0.1%	0%	Service Mode
900	Process information								
903	Current output Index 0 = fuel Index 1 = air	2	-	Reading only	0%	100%	0.1%	0%	Parameters Mode
910	Servomotors active	3	-	Reading only	0	1	1	0	Parameters Mode
922	Position of the servomotors Index 0 = fuel Index 1 = air	2	(°)	Reading only	-50°	150°	150°	0°	Service Mode
942	Heat source active	1	-	Reading only	0	255	1	0	Parameters Mode
947	Result of the sampling of the contact (codified in bits)	2	-	Reading only	0	255	1	0	Parameters Mode
950	Relay request status (coded in bits)	1	-	Reading only	0	255	1	0	Parameters Mode
954	Flame intensity	1	-	Reading only	0%	100%	1%	0%	Service Mode
961	Status of external modules and visualisation	1	-	Reading only	0	255	1	0	Parameters Mode
992	Error indicators	10	-	Reset	0	0xFFFFFFFF	1	0	Parameters Mode

If faults arise in ignition or operations, the burner performs a "safety stop", which is signalled by the red burner lockout LED. The display visualises alternately the lockout code and the relative diagnostic.

To reset the start-up conditions, refer to "Reset procedure". When the burner starts up again, the red LED goes out.

6.1 List of error codes

Error code	Diagnostic code	Meaning of the system REC27.100A2	Recommended measures
2	4	No flame at the end of TSA1	
3	#	Air pressure error	
	0	Air pressure switch off	
	1	Air pressure switch on	
	4	Air pressure on – Lockout alarm at start	
4	#	Extraneous light	
	0	Extraneous light during start-up	
	1	Extraneous light during switch-off	
	2	Extraneous light during start-up – Lockout alarm at start	
7	3	Loss of flame	
12	#	Valve leak detection / CPI	
	0	V2 leaks / CPI open	<u>Leak test</u> Check if the valve on the side of the burner has any leaks. Check if the pressure switch for the leak test (PGVP) is closed when gas pressure is not present. <u>CPI</u> Check the wiring. Check if the CPI contact is closed.
	1	V1 leaks / CPI closed	<u>Leak test</u> Check if the valve on the side of the gas has any leaks. <u>CPI</u> Check the wiring. Check if the CPI contact opens when the valve is powered.
20	0	Pmin Min. gas/oil pressure absent	
21	0	Pmax Max. gas/oil pressure exceeded	
22	0	Safety circuit open	
50 - 58	#	Internal error	Carry out a reset; if the error arises repeatedly, replace the control box
60	0	Internal error: no valid load checking device	Carry out a reset; if the error arises repeatedly, replace the control box
65 - 67	#	Internal error	Carry out a reset; if the error arises repeatedly, replace the control box
70	#	Fuel/air checking error: Calculation position in modulation	
	21	Invalid load	No valid load
	26	Curve points not defined	Adjust the curve points of all the actuators
71	#	Special position not defined	
	0	Standby position	Set the standby position of all the servomotors used
	1	Post-purging position	Set the post-purging position of all the servomotors used
	2	Pre-purging position	Set the pre-purging position of all the servomotors used
	3	Ignition position	Set the ignition position of all the servomotors used
72	#	Fuel/air internal checking error	Carry out a reset; if the error arises repeatedly, replace the control box
73	#	Fuel/air internal checking error	
	21	Position calculation, invalid stage load	No valid load
	26	Position calculation, stage curve points not defined	Adjust the curve points of all the servomotors
75	#	Fuel/air ratio internal checking error	
	1	Check synchronisation data, different current load	
	2	Check synchronisation data, different target load	
	4	Check synchronisation data, different target positions	
	16	Check synchronisation data, different positions reached	
76	#	Fuel/air internal checking error	Carry out a reset; if the error arises repeatedly, replace the control box
84	#	Servomotors curve slope	
	Bit 1 Valence 2..3	Fuel servomotor: Curve too steep in terms of train ratio	The slope of the curve can correspond to a maximum position variation of 31° between 2 points of the modulation curve
	Bit 2 Valence 4..7	Air servomotor: Curve too steep in terms of train ratio	The slope of the curve can correspond to a maximum position variation of 31° between 2 points of the modulation curve

Error code	Diagnostic code	Meaning of the system REC27.100A2	Recommended measures
85	#	Reference error of a servomotor	
	Bit 0 Valence 1	Reference error of the fuel servomotor	The reference of the fuel servomotor was not successful. It was not possible to reach the reference point. 1. Check if the servomotors have been inverted. 2. Check if the servomotor is blocked or overloaded.
	Bit 1 Valence 2...3	Reference error of the air servomotor	The reference of the air servomotor was not successful. It was not possible to reach the reference point. 1. Check if the servomotors have been inverted. 2. Check if the servomotor is blocked or overloaded.
	Bit 7 Valence ≥ 128	Reference error owing to parameter modification	The parameterization of an actuator (e.g. the reference position) has been modified. This error will be visualised to start up a new reference.
86	#	Fuel servomotor error	
	0	Position error	It was not possible to reach the target position within the requested tolerance range. 1. Check if the servomotor is blocked or overloaded.
	Bit 0 Valence 1	Circuit open	Circuit open shown on the servomotor connection. 1. Check the wiring.
	Bit 3 Valence ≥ 8	Curve too steep in terms of train ratio	The slope of the curve can correspond to a maximum position modification of 31° between 2 points of the modulation curve.
	Bit 4 Valence ≥ 16	Deviation of section compared with the last reference	Overloading of the servomotor or servomotor subjected to mechanical torsion. 1. Check if the servomotor is blocked in any point along its range of action. 2. Check if the torque is sufficient for the application.
87	#	Air servomotor error	
	0	Position error	It was not possible to reach the target position within the requested tolerance range. 1. Check if the servomotor is blocked or overloaded.
	Bit 0 Valence 1	Circuit open	Circuit open shown on the servomotor connection. 1. Check the wiring.
	Bit 3 Valence ≥ 8	Curve too steep in terms of train ratio	The slope of the curve can correspond to a maximum position modification of 31° between 2 points of the modulation curve.
	Bit 4 Valence ≥ 16	Deviation of section compared with the last reference	Overloading of the servomotor or servomotor subjected to mechanical torsion. 1. Check if the servomotor is blocked in any point along its range of action. 2. Check if the torque is sufficient for the application.
90 - 91	#	Burner internal checking error	
93	#	Flame signal acquisition error	
	3	Short circuit of the sensor	Short circuit in the QRB sensor... 1. Check the wiring. 2. Flame detector probably faulty.
95	#	Relay supervision error	
	3 Ignition transformer 4 Fuel valve 1 5 Fuel valve 2 6 Fuel valve 3	External power supply - Contact active	Check the wiring.
96	#	Relay supervision error	
	3 Ignition transformer 4 Fuel valve 1 5 Fuel valve 2 6 Fuel valve 3	The relay contacts have joined together	Check the contacts: 1. Control box connected to the power supply: the fan output must be without voltage. 2. Disconnect the power supply. Disconnect the fan. The resistive connection between the fan output and the neutral wire is not allowed. If one of the 2 tests fails, replace the control box because the contacts are definitively joined together and it is no longer possible to guarantee safety.
97	#	Relay supervision error	
	0	The safety relay contacts have joined together or the safety relay has been powered by an external power supply	Check the contacts: 1. Control box connected to the power supply: the fan output must be without voltage. 2. Disconnect the power supply. Disconnect the fan. The resistive connection between the fan output and the neutral wire is not allowed. If one of the 2 tests fails, replace the control box because the contacts are definitively joined together and it is no longer possible to guarantee safety.

Error code	Diagnostic code	Meaning of the system REC27.100A2	Recommended measures
98	#	Relay supervision error	
	2 Safety valve 3 Ignition transformer 4 Fuel valve 1 5 Fuel valve 2 6 Fuel valve 3	The relay does not start up	Carry out a reset; if the error arises repeatedly, replace the unit
99 - 100	#	Relay internal checking error	Carry out a reset; if the error arises repeatedly, replace the control box
105	#	Contact sampling internal error	
	0 Min. pressure switch 1 Max. pressure switch 2 Valve operation test pressure switch 3 Air pressure 4 Load controller open 5 Load controller on/off 6 Load controller closed 7 Safety loop / burner flange 8 Safety valve 9 Ignition transformer 10 Fuel valve 1 11 Fuel valve 2 12 Fuel valve 3 13 Reset	Blocked upon irregularity	Can be caused by capacitive loads or presence of DC voltage on the main power supply of the control box. The diagnostic code indicates the input in which the problem arose
106 - 108	#	Contact request internal error	Carry out a reset; if the error arises repeatedly, replace the control box
110	#	Voltage monitoring test internal error	Carry out a reset; if the error arises repeatedly, replace the control box
111	0	Low level of power supply	Insufficient mains voltage
112	0	Reset power supply voltage	Error code for the carrying out of a reset in the event of power supply restoration (absence of error)
113	#	Mains voltage supervision internal error	Carry out a reset; if the error arises repeatedly, replace the control box
115	#	Control box meter internal error	
116	0	Life cycle of the control box in the critical interval	The envisaged life cycle of the control box has been exceeded. Replace it.
117	0	Life cycle of the control box exceeded	The switch-off threshold has been reached.
120	0	Interruption of fuel limiting meter input	Too many disturbance impulses on the input of the fuel meter. Improve the electromagnetic compatibility.
121 - 124	#	EEPROM access internal error	Carry out a reset, repeat and check the last setting of the parameters. Restore the group of parameters. If the error arises repeatedly, replace the control box.
125	#	EEPROM reading access internal error	Carry out a reset, repeat and check the last setting of the parameters. If the error arises repeatedly, replace the control box.
126	#	EEPROM writing access internal error	Carry out a reset, repeat and check the last setting of the parameters. If the error arises repeatedly, replace the control box.
127	#	EEPROM access internal error	Carry out a reset, repeat and check the last setting of the parameters. Restore the group of parameters. If the error arises repeatedly, replace the control box.
128	0	EEPROM access internal error - synchronisation during the initialisation	Carry out a reset; If the error arises repeatedly, replace the control box.
129	#	EEPROM access internal error – command synchronisation	Carry out a reset, repeat and check the last setting of the parameters. If the error arises repeatedly, replace the control box.
130	#	EEPROM access internal error - time-out	Carry out a reset, repeat and check the last setting of the parameters. If the error arises repeatedly, replace the control box.
131	#	EEPROM access internal error - page interrupted	Carry out a reset, repeat and check the last setting of the parameters. If the error arises repeatedly, replace the control box.
132	#	EEPROM register initialisation internal error	Carry out a reset; If the error arises repeatedly, replace the control box.
133 - 135	#	EEPROM access internal error – request synchronisation	Carry out a reset, repeat and check the last setting of the parameters. If the error arises repeatedly, replace the control box.
136	1	Restoration started	The restoration of a backup has been started (no error)

Error code	Diagnostic code	Meaning of the system REC27.100A2	Recommended measures
137	#	Internal error – backup / restoration	
	157	Restoration – OK, but backup < compared with set data of current system	Restoration successful, but the backup data installed are fewer than those currently present in the system.
	242	Backup – the backup carried out is contradictory	The backup is irregular and cannot be transferred again
	243	Backup – the data comparison between the internal microprocessors is irregular	Repeat the reset and backup
	244	The backup data are incompatible	The backup data are incompatible with the current version of the software; the restoration is not possible
	245	Error in access to the parameter Restore_Complete	Repeat the reset and backup
	246	Restoration – time-out during logging in EEPROM	Repeat the reset and backup
	247	The data received are contradictory	The series of backup data is not valid; restoration is not possible
	248	The restoration cannot currently be carried out	Repeat the reset and backup
	249	Restoration – interruption caused by inadequate identification of the burner	The backup has an inadequate identification of the burner and must not be transferred to the control box
	250	Backup – the CRC of a page is not correct	The series of backup data is not valid; restoration is not possible
	251	Backup – the identification of the burner is not defined	Define the identification of the burner and repeat the backup
	252	After restoration, the pages are still in INTERRUPTION	Repeat the reset and backup
	253	The restoration cannot currently be carried out	Repeat the reset and backup
	254	Interruption owing to transmission error	Repeat the reset and backup
	255	Interruption owing to time-out during the restoration	Carry out a reset, check the connections and repeat the backup
146	#	Time-out of the system automation interface	Refer to the Modbus User Documentation (A7541)
	1	Modbus time-out	
	2	Reserved	
165	#	Internal error	
166	0	Watchdog reset internal error	
167	#	Manual lockout	The control box has been manually blocked (no error)
	1	Manual lockout from remote reset command	
	2	Manual lockout from Operator Panel	
	3	Manual lockout from PC interface	
168 - 171	#	Internal error management	Carry out a reset; if the error arises repeatedly, replace the control box
200	#	System free of errors	No error
201	#	Lockout or error at start	Lockout or error due to lack of parameter settings
	1	No operation mode selected	
	2..3	No fuel train defined	
	4..7	No curve defined	
	8..15	Standardisation speed not defined	
	16..31	Backup / restoration impossible	
202	#	Selection of internal operation mode	Redefine the operation mode (parameter 201)
203	#	Internal error	Redefine the operation mode (parameter 201) Carry out a reset; if the error arises repeatedly, replace the control box
204	Phase number	Program stop	The program stop is active (no error)
205	#	Internal error	Carry out a reset; if the error arises repeatedly, replace the control box
206	0	Combination of control box and Operator Panel not allowed	
207	#	Compatibility of control box with Operator Panel	
	0	Obsolete version of control box	
	1	Obsolete version of Operator Panel	
208-209	#	Internal error	Carry out a reset; if the error arises repeatedly, replace the control box
240	#	Internal error	Carry out a reset; if the error arises repeatedly, replace the control box
245	#	Internal error	Carry out a reset; if the error arises repeatedly, replace the control box
250	#	Internal error	Carry out a reset; if the error arises repeatedly, replace the control box

7.1 Notes on safety for the maintenance

The periodic maintenance is essential for the good operation, safety, yield and duration of the burner. It allows you to reduce consumption and polluting emissions and to keep the product in a reliable state over time.



The maintenance interventions and the calibration of the burner must only be carried out by qualified, authorised personnel, in accordance with the contents of this manual and in compliance with the standards and regulations of current laws.

Before carrying out any maintenance, cleaning or checking operations:



disconnect the electricity supply from the burner by means of the main switch of the system;



close the fuel interception tap;

7.2 Maintenance programme

Maintenance frequency

The gas combustion system should be checked **at least once a year** by a representative of the manufacturer or another specialised technician.

Checking and cleaning

Combustion

The optimum calibration of the burner requires an analysis of the flue gases. Significant differences with respect to the previous measurements indicate the points where more care should be exercised during maintenance.

Gas leaks

Make sure there are no gas leaks on the conduit between the gas meter and the burner.

Gas filter

Replace the gas filter when it is dirty.

Flame inspection window

Clean the glass of the flame inspection window.

Combustion head

Open the burner and make sure that all the components of the combustion head are:

- undamaged;
- not deformed due to high temperature;
- free of ambient dirt or dust;
- free of rusted materials;
- adequately positioned.

Make sure that the gas outlet holes for the start-up, on the combustion head distributor, are free of dirt or rust deposits.

In case of doubt, disassemble the elbow 5)(Fig. 39).

Combustion

Adjust the burner if the combustion values found at the beginning of the operation do not comply with the regulations in force or, at any rate, do not produce good combustion.

Use the appropriate card to record the new combustion values; they will be useful for subsequent controls.

7.3 Opening the burner

- **Disconnect the electrical supply from the burner.**
 - Loosen the 4 screws 1) and remove the hood 2).
 - Assemble the two extensions supplied on the guides 4) (versions TL).
 - Disconnect the plug 7) (Fig. 12) and loosen the grommet 8);
 - Disconnect the socket of the maximum gas pressure switch;
 - Remove the screws 3) and pull back the burner on the guides 4) by about 100 mm. Disconnect the cables of the probe and electrode, then pull the burner back completely.
- At this point it is possible to extract the inner part 5) after having removed the screw 6).

7.4 Closing the burner

- Push the burner up to approximately 100 mm from the pipe coupling.
- Reinsert the cables and slide the burner as far as the stop.
- Connect the plug of the servomotor 7) and tighten the grommet 8) (Fig. 12).
- Connect the socket of the maximum gas pressure switch.
- Replace the screws 3) and carefully pull the probe and electrode cables outwards until they are slightly taut.
- Disassemble the two extensions from the guides 4).





Fig. 39


1	Index of layouts
2	Indication of references
3	Functional layout REC27...
4	Functional layout REC27...
5	Functional layout REC27...
6	Electrical wiring that the installer is responsible for
7	Functional layout RWF40...


2 Indication of references





Wiring layout key


A1	- Control box for the air/fuel ratio	K1	- Clean contacts output relay burner switched on
A2	- Operator panel	K2	- Clean contacts output relay burner lockout
+BB	- Burner components	KM	- Fan motor contact maker
+BC	- Boiler components	MV	- Fan motor
B	- Filter to protect against radio disturbance	PA	- Air pressure switch
B1	- Output regulator RWF40	PE	- Burner earth
B2	- Fuel meter	PGM	- Maximum gas pressure switch
BA	- Input in current DC 4...20 mA	PGMin	- Minimum gas pressure switch
BA1	- Input in current DC 4...20 mA to modify remote setpoint	PGVP	- Gas pressure switch for valve leak detection control device
BP	- Pressure probe	Q1	- Three-phase disconnecting switch
BP1	- Pressure probe	Q2	- Single phase disconnecting switch
BR	- Remote setpoint potentiometer	RS	- Remote burner reset button
BT1	- Thermocouple probe	S1	- On/off selector
BT2	- Probe Pt100, 2 wires	SM1	- Air servomotor
BT3	- Probe Pt100, 3 wires	SM2	- Gas servomotor
BT4	- Probe Pt100, 3 wires	TA	- Ignition transformer
BTEXT	- External probe for climatic compensation of the setpoint	TL	- Limit thermostat/pressure switch
BV	- Input in voltage DC 0...10V	TR	- Adjustment thermostat/pressure switch
BV1	- Input in voltage DC 0...10V to modify remote setpoint	TS	- Safety thermostat/pressure switch
CN1	- Ionisation probe connector	X1	- Burner terminal strip
F1	- Fan motor thermal relay	XP1	- Connector for output power regulator kit RWF40
G1	- Load indicator	XPD	- Operator panel connector
G2	- Communication interface for Modbus system	XPGM	- Maximum gas pressure switch connector
H	- Remote lockout signal	XPGVP	- Gas pressure switch connector for valve leak detection control device
ION	- Ionisation probe	XRWF	- Terminal board for output power regulator RWF40
IN	- Manual burner arrest switch	Y	- Gas adjustment valve + gas safety valve














Output power regulator kit for modulating operation

With the modulating operation, the burner continually adapts the power to the request for heat, ensuring great stability for the parameter controlled: temperature or pressure.

Two components should be ordered:

- the output regulator to install on the burner;
- the probe to install on the heat generator.

Parameter to be checked		Probe		Output regulator	
	Adjustment field	Type	Code	Type	Code
Temperature	- 100...+ 500°C	PT 100	3010110	RWF40	3010414
Pressure	0...2.5 bar	Output probe	3010213		
	0...16 bar	4...20mA	3010214		

Software interface kit (ACS410 + OCI410.30) - Service Level

Code 3010436

Modbusinterface Kit (OCI412)

Code 3010437

Gas trains in compliance with standard EN 676 (complete with valves, pressure adjuster and filter)

Gas train - burner adapters

Gas train			Gas train coupling on burner				Gas train - burner adapter
Code	Model	Ø	RS 68/E	RS 120/E	RS 160/E	RS 200/E	Code
3970256	Multibloc MB DLE 412 S52	1"1/4	•	•			3010126
3970250	Multibloc MB DLE 415 S52	1"1/2	•	•	•	•	3000843
3970257	Multibloc MB DLE 420 S52	2"	•	•	•	•	-
3970221	MBC-1200-SE -50	2"	•	•	•	•	-
3970222	MBC-1900-SE-65 FC	DN 65	•	•	•	•	3000825
3970223	MBC-3100-SE-80 FC	DN 80			•	•	3000826

PVP kit (Pressure Valve Proving)

Code 3010344 for RS 68/E BLU

Note: for RS 120/E BLU, RS 160/E BLU and RS 200/E BLU models, the Kit is supplied as standard equipment with the burner.

Kit per Funzionamento A GPL

Burner		RS 200/E BLU
OUTPUT	kW	630 ÷ 2400
CODE		3010491

Continuous Purging Kit

Code 3010094

Pipes Kit (for flame inversion boilers)

Burner	Kit Code
RS 68/E BLU	3010247
RS 120/E BLU	3010248
RS 160/E BLU	3010249

Long Head Kit

Burner	Kit Code	Standard head length	Head length obtained with the kit
RS 68/E BLU	3010177	255 mm	390 mm
RS 120/E BLU	3010177	255 mm	390 mm
RS 160/E BLU	3010442	373 mm	503 mm
RS 200/E BLU	3010474	373 mm	503 mm

The adjacent tables show minimum load losses along the gas supply line depending on the maximum burner output operation.

Column 1

Load loss at combustion head.

Gas pressure measured at the test point 1)(Fig. 40), with:

- Combustion chamber at 0 mbar;
- Burner working at maximum output;
- Ring nut 2)(Fig.16) adjusted as in the diagram of Fig. 17

Column 2

Load loss at gas butterfly valve 2)(Fig. 40) with maximum opening: 90°.

Column 3

Load loss at train 3)(Fig. 40) including: adjustment valve VR, safety valve VS (both fully open), pressure adjuster R, filter F.

The values shown in the tables refer to:

natural gas G 20 PCI 9.45 kWh/Sm³

(8.2 Mcal/Sm³)

With:

natural gasG 25 PCI 8.13 kWh/Sm³

(7.0 Mcal/Sm³) multiply the values of the tables:

- columns 1-2: by 1.5;
- column 3: by 1.35.

To know the approximate output at which the burner is operating at its maximum:

- subtract the combustion chamber pressure from the gas pressure measured at test point 1)(Fig. 40);
- find, in the table relating to the burner concerned, column 1, the pressure value closest to the result you want;
- read the corresponding output on the left.

Example - RS 68/E BLU:

- Maximum output operation
 - Natural gas G 20 PCI 9.45 kWh/Sm³
 - Ring nut 2)(Fig. 16) adjusted as in the diagram of Fig. 17
 - Gas pressure at test point 1)(Fig. 40) = 11.6 mbar
 - Pressure in combustion chamber = 3.0 mbar
- $$11.6 - 3.0 = 8.6 \text{ mbar}$$

A maximum output of 700 kW shown in Table RS 68/M corresponds to 8.6 mbar pressure, column 1.

This value serves as a rough guide; the effective output must be measured at the gas meter.

RS 68/E BLU

Δp (mbar)

kW	1	2	3				
			Ø 1"1/4 3970256	Ø 1"1/2 3970250	Ø 2" 3970257	Ø 2" 3970221	DN 65 3970222
350	2,0	0,1	11,3	6,1	4,3	3,6	3,3
400	3,0	0,1	14,1	7,4	5,2	3,8	3,4
450	3,9	0,1	17,0	8,8	6,1	4,0	3,5
500	5,0	0,2	19,9	10,1	7,0	4,2	3,6
550	5,8	0,2	23,2	11,6	8,2	4,4	3,7
600	6,8	0,2	26,7	13,2	9,5	4,6	3,9
650	7,7	0,3	30,3	14,7	10,8	4,9	4,1
700	8,6	0,3	34,0	16,4	12,1	5,1	4,2
750	9,7	0,4	37,7	18,0	13,4	5,4	4,4
800	10,6	0,4	41,5	19,9	14,8	5,8	4,6
860	11,7	0,5	46,1	22,2	16,5	6,3	4,9

RS 120/E BLU

Δp (mbar)

kW	1	2	3				
			Ø 1"1/4 3970256	Ø 1"1/2 3970250	Ø 2" 3970257	Ø 2" 3970221	DN 65 3970222
600	4,4	0,3	26,7	13,2	9,5	4,6	3,9
650	6,0	0,3	30,3	14,7	10,8	4,9	4,1
715	7,9	0,4	35,1	16,9	12,5	5,2	4,3
760	9,2	0,4	38,4	18,3	13,7	5,5	4,5
825	10,8	0,5	43,4	20,9	15,5	6,0	4,7
890	12,4	0,6	48,3	23,4	17,4	6,5	5,0
955	14,0	0,6	53,6	26,0	19,3	7,1	5,3
1020	15,5	0,7	60,4	28,5	21,2	7,6	5,6
1090	17,2	0,8	67,6	31,5	23,5	8,3	6,0
1170	18,7	1,0	76,0	34,8	26,2	9,1	6,5
1250	21,0	1,1	-	38,2	28,9	9,9	6,9
1300	22,5	1,2	-	40,5	30,9	10,6	7,3

RS 160/E BLU

Δp (mbar)

kW	1	2	3				
			Ø 1"1/2 3970250	Ø 2" 3970257	Ø 2" 3970221	DN 65 3970222	DN 80 3970223
930	5,6	1,0	25,0	18,6	8,2	5,2	3,9
1000	6,4	1,1	27,7	20,6	8,9	5,5	4,0
1100	7,5	1,3	31,9	23,9	10,2	6,1	4,3
1200	8,6	1,6	36,1	27,2	11,6	6,7	4,6
1300	9,7	1,9	40,5	30,9	13,1	7,3	4,9
1400	10,8	2,2	45,9	35,2	15,0	8,1	5,2
1500	11,9	2,5	51,2	39,6	17,0	8,9	5,5
1600	13,0	2,8	56,5	43,9	19,0	9,8	5,8
1700	14,6	3,2	61,8	48,3	21,0	10,7	6,1
1800	16,5	3,6	67,2	52,7	23,1	11,5	6,5
1860	17,7	3,8	70,4	55,3	24,3	12,1	6,7

To know the required gas pressure at test point 1)(Fig. 40), set the maximum output required from the burner operation, then:

- find the nearest output value in the table for the burner in question.
- read, on the right (column 1) the socket pressure 1)(Fig. 40);
- add this value to the estimated pressure in the combustion chamber.

Example - RS 68/E BLU:

- Maximum output required: 700 kW
 - Natural gas G 20 PCI 9.45 kWh/Sm³
 - Ring nut 2)(Fig. 16) adjusted as in the diagram of Fig. 17
 - Gas pressure at output of 700 kW, taken from table RS 68/M BLU, column 1 = 8.6 mbar
 - Pressure in combustion chamber = 3.0 mbar
- $$8.6 + 3.0 = 11.6 \text{ mbar}$$
- pressure required at socket 1)(Fig. 40).

RS 200/E BLU

Δp (mbar)

kW	1	2	3				
			\varnothing 1"1/2 3970250	\varnothing 2" 3970257	\varnothing 2" 3970221	DN 65 3970222	DN 80 3970223
1383	9,0	3,1	44,5	34,1	11,7	7,9	5,1
1400	9,3	3,2	45,9	35,2	12,1	8,2	5,2
1500	10,7	3,7	51,2	39,6	13,6	9,0	5,5
1600	12,0	4,2	56,5	43,9	15,2	9,8	5,8
1700	13,3	4,7	61,8	48,3	16,7	10,7	6,1
1800	14,7	5,3	67,2	52,7	18,2	11,5	6,4
1900	16,0	5,9	72,5	57,0	19,8	12,4	6,9
2000	18,2	6,5		62,2	21,6	13,5	7,3
2100	20,3	7,2		67,6	23,5	14,6	7,7
2235	22,5	7,9		73,0	25,4	15,8	8,2
2300	24,9	8,6		78,3	27,3	17,0	8,7




Fig. 40

The firing rate of the burner shown in the manual is valid for a room temperature of 20°C and an altitude of 0m above sea level (barometric pressure around 1013 mbar).

It may be that a burner has to operate with combusive air at a higher temperature and/or higher altitudes.

The heating of the air and the increase in altitude produce the same effect: the expansion of the air volume (i.e. the reduction of its density).

The delivery of the burner fan remains essentially the same, but the oxygen per m³ of air, and the thrust (discharge head) of the fan are reduced.

It is therefore important to know if the maximum output requested from the burner at a determinate combustion chamber pressure remains within the firing rate of the burner even with the changed temperature and altitude conditions.

To check it, proceed as follows:

- 1 -Find the corrective factor F (relating to the air temperature and altitude of the system) in the table alongside
- 2 -Divide the output Q required from the burner by F to obtain the equivalent output Qe:

$$Q_e = Q : F \text{ (kW)}$$

- 3 -In the firing rate of the burner, mark the work point identified by:

Qe = equivalent output

H1 = pressure in combustion chamber

point A that must remain within the firing rate (Fig. 41)

- 4 -Trace a vertical line from point A, Fig. 41, and find the maximum pressure H2 of the firing rate

- 5 -Multiply H2 by F to obtain the maximum lowered pressure H3 of the firing rate

$$H3 = H2 \times F \text{ (mbar)}$$

If H3 is greater than H1, as in Fig. 41, the burner can produce the delivery requested.

If H3 is less than H1, it is necessary to reduce the output of the burner. The reduction in output is accompanied by a reduction in the combustion chamber pressure:

Qr = reduced output

H1r = reduced pressure

$$H1r = H1 \times \left(\frac{Q_r}{Q} \right)^2$$

Example, 5% reduction in output:

$$Q_r = Q \times 0.95$$

$$H1r = H1 \times (0.95)^2$$

With the new values - Qr and H1r - repeat steps 2 - 5.

Warning:

the combustion head should be adjusted in relation to the equivalent output Qe.

Altitude m. above sea level	Average barometric pressure mbar	F							
		Air temperature °C							
		0	5	10	15	20	25	30	40
0	1013	1.087	1.068	1.049	1.031	1.013	0.996	0.980	0.948
100	1000	1.073	1.054	1.035	1.017	1.000	0.983	0.967	0.936
200	989	1.061	1.042	1.024	1.006	0.989	0.972	0.956	0.926
300	978	1.050	1.031	1.013	0.995	0.978	0.962	0.946	0.916
400	966	1.037	1.018	1.000	0.983	0.966	0.950	0.934	0.904
500	955	1.025	1.007	0.989	0.972	0.955	0.939	0.923	0.894
600	944	1.013	0.995	0.977	0.960	0.944	0.928	0.913	0.884
700	932	1.000	0.982	0.965	0.948	0.932	0.916	0.901	0.872
800	921	0.988	0.971	0.954	0.937	0.921	0.906	0.891	0.862
900	910	0.977	0.959	0.942	0.926	0.910	0.895	0.880	0.852
1000	898	0.964	0.946	0.930	0.914	0.898	0.883	0.868	0.841
1200	878	0.942	0.925	0.909	0.893	0.878	0.863	0.849	0.822
1400	856	0.919	0.902	0.886	0.871	0.856	0.842	0.828	0.801
1600	836	0.897	0.881	0.866	0.851	0.836	0.822	0.808	0.783
1800	815	0.875	0.859	0.844	0.829	0.815	0.801	0.788	0.763
2000	794	0.852	0.837	0.822	0.808	0.794	0.781	0.768	0.743
2400	755	0.810	0.796	0.782	0.768	0.755	0.742	0.730	0.707
2800	714	0.766	0.753	0.739	0.726	0.714	0.702	0.690	0.668
3200	675	0.724	0.711	0.699	0.687	0.675	0.664	0.653	0.632
3600	635	0.682	0.669	0.657	0.646	0.635	0.624	0.614	0.594
4000	616	0.661	0.649	0.638	0.627	0.616	0.606	0.596	0.577




Fig. 41

The logo consists of the word "RIELLO" in a bold, red, sans-serif typeface. The letters are closely spaced and have a uniform thickness.

RIELLO S.p.A.

I - 37045 Legnago (VR)

Tel.: +39.0442.630111

[http:// www.riello.it](http://www.riello.it)

[http:// www.rielloburners.com](http://www.rielloburners.com)

Subject to modifications